

ASSEMBLY AND OPERATING INSTRUCTIONS

CONTENTS

Ⅰ About The Product

1-1 Product Information 2

1-2 Parts List 3

Ⅱ Installation Steps

2-1 Tools Required For Installation 8

2-2 Safety Tips 9

2-3 Inspection And Acceptance 9

2-4 Install The Frame 10

2-5 Install The Canopy 16

Ⅲ Appendix


3-1 User's Manual 25


3-2 After-sales Service 26


3-3 Product Maintenance 27

3-4 Disclaimer 28

3-5 More Products 29







Product Information


Product Name	Patio Gazebo
Model Name	TB47
Color	Black
Top Material	Metal
Bracket Material	Cedar Wood
Specifications	10 ft x 10 ft
Applicable Season	Four Seasons
Applicable Venue	Courtyard, Backyard, Garden, Patio, Deck and Lawn

Parts Of Frame

Part#	Frame component	Qty
A-2		X4
B4		X4
B5		X4
B2		X4
B3		X4
M-2		X8
WW		X12


Metal Fastenings

A2-5



X4

A2-6





X4

L-1




X4

Parts of Top

Part#	Supports	Qty
P1-8		X4
P1-9		X4
P1-10		X4
P3-5		X4
P15-3		X4
P15-4		X4
P16-3		X4
P16-4		X4
P16-5		X4
P16-6		X4


Roof Panel

P17-1




X4

P17-4




X4

P17-5




X4

P17-6



X4

P17-7



X4

P19-1



X4

Parts of Top


Metal Fastenings

P1-5



X4

P3-4




X4

P5-5




X4

P5-6



X4

P8-4



X1

P8-5



X1

P9



X1

Connection for Roof Panel

P18-1




X4

P18-2






X8


Parts List

Part#			Qty
BB	M6x28		4
GG	M6		9
JJ	M6		2
WW	φ8x180		12
XX			1
YY	M6x16		100
BBB	M10		8
CCC	M10		8
DDD	M8x65		16
EEE	M8		16
FFF	M8		32
GGG	M6x55		8

Parts List


Part#			Qty
HHH	M6		8
III	M5x30		64
JJJ	M8		2
KKK	M10		2
LLL	M8x115		12
MMM	M8x35		16
NNN	M10x135		8
OOO	M10x70		8
PPP	M10		1
QQQ	M8		1


Recommended number





Needed for assembly

(The following tools are not included)









Safety Tips

1. If any parts are missing, broken, damaged, or frayed, **do not use this product until repairs have been made and/or replacement parts have been installed.**

2. Place the item on a **stable** and **level** surface.

3. Do not use or store this item near open **flames** or **flammable/combustible chemicals**.

4. Do not attempt to assemble this item under the following circumstances:

   (1) Drunk **(2) Inclement weather**

   (3) Lack of tools or parts **(4) Without assistance**

5. **Secure** all bolts, screws and knobs firmly before use.

6. **Reassure** that all bolts, screws and knobs are secure **every 90 days**.

Inspection And Acceptance

After the installation of the gazebo is completed, it needs to be inspected to ensure that all functions are normal and the structure is safe. Here are the steps to check and accept a patio gazebo:

1. **Gazebo**: Check that the gazebo is in good condition, with no visible scratches, damage or stains. Does the color and material of the gazebo match the description at the time of purchase.

2. **Parts and Hardware**: Check that all parts and tools are in accordance with the instructions.


Feel free to contact the customer service team if you have any questions. We will provide you with a satisfactory solution!

Step 1


A-2
X4



A2-5
X4




A2-6
X4



III
X12







Step 2

B4
X4




B5
X4





LLL
X 12







Step 3





Step 4


B2
X4
B3
X4
EEE
X16
DDD
X16
FFF
X32
MMM
X16


FFF
EEE
FFF
DDD
B3
B2
DDD
FFF
FFF
MMM
MMM
B2
B3
d2
d1
B2
B3

Step 5

M-2
X8





Step 6

P5-6
X4



III
X20



Step 7

P1-8
X4

P1-9
X4

P1-10
X4

P8-4
X1

YY
X36



Step 8

P3-5
X4


GGG
X8

P5-5
X4

GG
X8

YY
X4

HHH
X8



Step 9

P16-3
X4




P16-4
X4




P16-5
X4



YY
X16



P16-6
X4



Step 10

P15-3
X4

P15-4
X4


P3-4
X4

P1-5
X4

YY
X4


BB
X4

III
X 16



Step 11

P8-5
X1




P9
X1



GG
X1





Step 12


P19-1


X4






Step 13


P17-5
X4
P17-6
X4
P17-7
X4
P17-1
X4
P17-4
X4


P17-6
P17-6



P17-4
P17-7
P17-6
P17-5
P17-1
P17-5
P17-6
P17-7
P17-4
P17-1

Step 14

P18-1
X4




YY
X40



P18-2
X8





Step 15

WW

X 12





User's Manual

Matters Needing Attention

1. **Weather Factors**: In extreme blizzard weather, please clear the top of the snow in time.
2. **Maintenance**: Please varnish the wooded parts regularly to extend the service life of the wood gazebo.
3. **Periodic Inspection**: Tighten all screws and connecting parts regularly.
4. **Stability and Sturdiness**: Be sure to nail the bottom of the four legs to make the gazebo more stable and Serviceable.

By following the above recommendations, you can have a longer, more reliable and comfortable experience with your patio canopy.

Common Problems And Solutions

1. How should the gazebo cope with **extremely blizzard weather**?
   - Clear the top of the snow in time.
2. What if parts or hardware are **lost** during installation?
   - Please contact customer service promptly and stop using or installing the gazebo before the parts or tools arrive.
3. What if the gazebo is **damaged** during use?
   - Please stop daily use immediately to ensure the safety of you and your family, contact customer service, provide pictures of the damage, and repair the gazebo under the guidance of customer service. Make sure the gazebo is in good condition before you reuse it.
4. How often is it recommended to **maintain** the wood part?
   - Every three months.
5. Can wood parts be **drilled** and **modified** at will?
   - We do not recommend this. Because this will affect the stability of the entire structure and cause certain security risks.

After-sales Service

1. Free return within 30 days.

2. Free replacement is available within 60 days.

3. Products need to be returned in their original packaging.

4. If the product is damaged, contact customer service promptly and provide relevant pictures.

5. Refunds that have been processed will generally be returned to the original account within 5-10 business days.

6. If you do not receive the product within the effective time, contact customer service to resolve them in a timely manner.

7. If you find something was missing during the assembly process, please stop the installation first, then take a picture of the manual and mark the missing part, and then contact our customer service. They will provide you with the best solution.

8. If you find that the product is aged or damaged during use and would like to purchase a replacement, please contact our customer service and we will provide you with the most cost-effective replacement solution.

Product Maintenance

1. **Regular Cleaning**: The top can be rinsed with a hose, and the columns can be wiped with a damp rag.

2. **Periodic Inspection**: Check screws and connecting iron parts for loosening and support structures for breakage. If yes, contact customer service in time and repair under the guidance of customer service.

3. **Protection From Extreme Snowstorms**: Clear the accumulated snow at the top in time to reduce the load.

4. **Maintenance Of Wood Parts**: The wood parts need to be regularly varnished to prevent rot and insects.

Disclaimer

Thank you for choosing our gazebo! To protect you and your family, please read and strictly follow the following items:

1. During assembly and use, be careful about safety and **follow** product **instructions** and **safety tips** to avoid accidents.

2. If the product is **damaged** as a result of **human action** or **weather, stop using** it immediately and **contact** our **customer service** promptly.

3. If the gazebo cannot be used properly due to the force majeure factor, we will not be liable for the losses incurred.

4. Please make sure that your use of the gazebo **does not interfere** with the normal life and work of others. Please **schedule your time** properly and avoid setting up and using the gazebo during other people's breaks.


5. Please **observe** the **local laws** and **regulations** and set up and use the gazebo according to the rules. Be sure to follow the requirements for erecting and using a gazebo if there are special requirements in local laws and regulations.

6. Please take care of the surrounding environment during the erection and use of the gazebo to avoid causing damage to surrounding buildings, facilities and the natural environment.

7. Please **check** the structural and safety condition of the gazebo **regularly**, and if you find anything **out of the ordinary**, **repair** or **replace** it promptly. If you are not sure how to inspect or repair it, please contact our customer service.

8. Please **respect** the **legitimate rights** and **interests of others**. If you spot someone entering your gazebo area without authorization, stop using the gazebo immediately and report it to the appropriate authorities.

We sincerely hope that you can fully enjoy the comfort and convenience when using the canopy, and at the same time ensure the safety of you and others. If you encounter any problems during the use, please feel free to contact our customer service, we will be happy to serve you.




Product Name: Deluxe Double Top Cantilever Umbrella

Available Size: 9x9FT / 9x19FT / 10x10FT / 10x13FT / 11x11FT

Available Colors: Burgundy, Turquoise, Dark Gray, Navy Blue, Light Beige, Rust Red, Black

Model Name: UL80




Product Name: Wood Gazebo with Double Roof

Available Size: 11x11FT / 11x13FT

Available Colors: Black

Model Name: TB48




Product Name: Hardtop Gazebo with Metal Roof

Available Size: 6x8FT / 8x8FT / 10x10FT / 10x12FT / 12x12FT / 12x16FT / 12x20FT

Available Colors: Dark Brown Gray Khaki Wood Grain

Model Name: TA55




Product Name: Outdoor Gazebo with Soft Top

Available Size: 8x8FT / 10x10FT / 10x12FT

Available Colors: Dark Gray Khaki Beige Navy Blue Rust Red Green Black

Model Name: TP16




Product Name: Grill Gazebo Canopy

Available Size: 8x5FT

Available Colors: Dark Brown, Green, Khaki, Burgundy, Rust Red, Brown

Model Name: SK02




Product Name: Patio Double-Sided Umbrella

Available Size: 15FT

Available Colors: Dark Gray, Brown, Khaki, Navy Blue, Orange, Burgundy, Green, Blue, Red

Model Name: UB02




Product Name: Patio Pop Up Canopy Tent Commercial-Series

Available Size: 8x8FT / 8x12FT / 8x16FT / 10x10FT / 10x15FT / 10x20FT

Available Colors: White, Royal Blue, Gray, Beige, Orange, Black, Navy blue, Red, Green, Turquoise

Model Name: CT03



Product Name: Outdoor Adirondack Chair

Available Size: Seat Width 20" / Seat Width 21.6"

Available Colors: White, Dark Gray, Turquoise, Black, Light Brown

Model Name: XZ19

Embrace the Joys of Life

