## **USER MANUAL**

Thank you for purchasing our product.

For questions or assistance on assembly, parts or installation, please contact customer support

Please include the product number, order number if any, and your phone number in the email. If there are broken or missing parts, please include the part numbers and quantities, and your address.

For hard to explain problems, please send us a few pictures showing the problems if you can. We involve the factory technicians directly in the support, so you can be assured you will deal with the experts.

## CAUTION

1. Rated 110-130V/60Hz, bulb 40W-60W maximum.

2. Care should be taken to avoid damage to the surface of lighting and wire. Wearing gloves are recommended when installing.

3. Keep lighting away from acid, alkali and other corrosive chemical or gas. Clean the lighting with clean soft cloth only.

4. Installation must be carried out by qualified electrician only.

- 5. Disconnect the power before installing, cleaning and replacing lighting.
- 6. Never cover the lighting when power is connected.



The wiring connection of luminaire and outlet box

There are two main wires. One is in black and the other is in white. Be sure to connect the black wire (positive electrode) to the outlet box wire (positive electrode), the white wire (negative electrode) to the outlet box wire (negative electrode) and the copper fixture ground wire to the supply ground wire with wire connectors.



## INSTRUCTION

1A. Lock the mounting bracket on the junction box of the wall by using 2 pcs of 5/32 screws in the accessories bag.

1B. Connect the wires. The black wire is the positive (+) wire. The white wire is the negative (-) wire. The bare wire is the ground wire.

1C. Cover the wall plate and attach the screws to the wall plate.



Please note: The parts in this table are completely unassembled, for illustrative purpose. In the actual product that you receive, some parts are assembled and attached together.



