




# ASSEMBLY INSTRUCTIONS




**OR**



# WARNING !



**MAXIMUM LOAD**  
**110lb / 50kg**




**MAXIMUM LOAD**  
**20 lb / 9.1kg**




Estimated Time for Assembly

**30 mins**





Assemble the furniture on empty carton, carpet, or rug to prevent scratches or damage.














This furniture requires 2 people to assembly.


Make sure no parts are missing or damaged before assembly.

# PACKAGE CONTENT




A	x40+1	B	x40+1	C	x40+1	D	x1	E	x12+1	F	x8
											
$\varnothing 6 \times 35$		$\varnothing 15 \times 9.5$		$\varnothing 7 \times 30$		M4		$\varnothing 3 \times 14$			
G	x2	H	x24+1	J	x4	K	x4	L	x2		
											
		$\varnothing 4 \times 12$				M4x22					

# STEP 1




# STEP 2


Push a CAM LOCK into the part.  
The arrow in the CAM LOCK must point toward the hole on the edge of the board.






# STEP 3



# STEP 4







# STEP 5




B	X4	C	X4
$\varnothing 15 \times 9.5$		$\varnothing 7 \times 30$	

# STEP 6




A	X4	B	X4	C	X4
$\varnothing 6 \times 35$		$\varnothing 15 \times 9.5$		$\varnothing 7 \times 30$	


# STEP 7






# STEP 8



# STEP 9



**FINISH!**

E	X2	G	X1	H	X8
					
3x14				φ4x12	



# FURNITURE CARE AND MAINTENANCE

## Particleboard

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



### MAINTENANCE

- Tighten all bolts and screws again within the first 2 weeks of assembly
- Check the tightness of all bolts every 2 months, tighten them if necessary



### CLEANING

- Clean the surface of the MDF (medium - density fiberboard) with a lightly dampened cloth.
- Small amount of mild soap can be used if necessary
- Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol detergent to clean the surface.

⚠ DO NOT apply wood treatment on parts made with MDF.

Medium - density fiberboard will swell and distort when suffer from water damage. Make sure to dry the furniture immediately after cleaning