


Owner Manual



WARRANTY

We strive to offer high quality product and we also try our best to satisfy each customer that order from us, no matter on products or services as needed. Each customer receives a record of their order, such as the order number or item receipt. For any items that are out of warranty period, you may still be able to purchase the replacement parts from our company if they are available.



MAINTENANCE AND WARNING

Please read the manual thoroughly
before you start installing.

Please keep the product away from
sharp object.

Packaging and small parts may have
chocking hazard, please keep them away
from children and pets.

Please clean the product according to each
clean code, check the product description
for more information.

Please keep the product away from
fire.


If you have any other questions, please
contact us, we will be glad to help you out.

If the product is placed under direct
sunlight, the pattern or color might fade
away overtime.

Check the product periodically to make
sure everything is secured and tightened.

Always use proper tools for installation.

Do not jump on the product.



Around 15 min

PRODUCT DESCRIPTION

Cotton blend. Exceptionally soft, and skin-friendly to the touch.

The surface offers visual and tactile warmth, significantly enhancing seating comfort and a cozy feel.

Solid wood frame, highlighted by the bent design of the rear legs and protective glides on each foot. The bent legs offer strong visual appeal and improve structural mechanics. The glides protect the wood from wear and add a refined detail.

High-density foam filling. The seat and backrest are plumply cushioned, providing immediate soft support and proper resilience. Effectively alleviates pressure from prolonged sitting, ensuring comfort during meals or short breaks.



Minimalist dining chair. The core design features a curved backrest with a sleek, sculptural look.. With smooth, gentle lines and a unique silhouette, it incorporates a touch of flexible and sculptural quality into minimalism, moving beyond the rigid look of ordinary chairs.

Ergonomic curved backrest: The backrest's arc naturally follows the spine's curve for just-right support.

EXPLODED VIEW




Every screw must be fully tightened.
If the chair makes unusual noise
during use, simply retighten the
screws with the supplied Allen key.




PARTS

A(R)*1



Rear Legs

B (R)*1



Rear Legs

C*1



Backrest

A(F)*1



Front Legs

B(F)*1



Front Legs

E*1



Seat frame

* (R):Rear (F):Front


The number of parts of this chair is what is needed to assemble one chair.

HARDWARE

TOOL LIST


NOTE: Designated with (★) We provide additional spare parts in the hardware package

①*4



★ M6*30mm
Bolt

②*8




★ M6*65mm
Bolt

③*4



★ M6*16mm
Flat washer

④*1



Allen Key

⑤*1



Metal plate

⑥*4




★ M6*12mm
Flat washer

Please make sure all hardware & packing material fitting the list. Especially some small accessories may be missing during transportation. Please contact us if you have any question.

step 1 ---Install the legs


Attach the wooden legs (A) to the seat frame (E) using bolt (2) & Flat washer (3) and Allen wrench (4), tighten the bolt fully.



First add one flat washer on each bolt as shown, use the allen wrench provided to tighten all the bolts by 30-50% first, make sure that all bolts are aligned correctly before fully tightening.

step 2 ---Install the legs

Attach the wooden legs (B) to the seat frame (E) using bolt (2) & Flat washer (3) and Allen wrench (4), tighten the bolt fully.




step 3 ---Install metal plate

Attach the metal plate (5) to the wooden legs using bolt (2) & Flat washer (3) and Allen wrench (4),tighten the bolt fully.

Notice:

We suggest tightening the bolts for 30-50% first, make sure the process is correct and bolt holes are aligned, then fully tightening them all.




step 4 ---Install the Backrest

Attach the Backrest (C) to the wooden legs using bolt (1) & Flat washer (6) and Allen wrench (4),tighten the bolt fully.





First add one flat washer on each bolt as shown, use the allen wrench provided to tighten all the bolts by 30-50% first, make sure that all bolts are aligned correctly before fully tightening.



step 5 ---Adjust the legs of the chair

Please note: the legs of the chair can be adjusted by twisting the leveler on the tip of the legs as shown, it can help you use this chair on ground that is not flat, please check before you use the chair.



step 6 ---Assemble Complete

Place the chair properly and tidy it up to make it look nice.
Assembly is complete. Thank you for choosing our product!
Please enjoy!

