

If there are any missing parts, damaged packaging or broken panels,
please contact our service email for assistance:


furni-service@outlook.com

CONTACT US!

Do Not return this product

If you encounter any missing parts, damaged packaging, or broken panels, please contact our customer service team for assistance:

①



Email:

furni-service@outlook.com

②



Amazon Message

③



Call or Message:

+1 (909) 960-3666

④
















WhatsApp

For faster resolution:


① Include your **order number** ② Attach **clear photos** of the issue



We appreciate your patience and cooperation, and we'll do our best to resolve your concern promptly. Thank you!





<p>A</p>  <p>M6*35MM 51+2PCS</p>	<p>B</p>  <p>15MM*9MM 51+2PCS</p>	<p>C</p>  <p>Ø8*30MM 31+2PCS</p>	<p>D</p>  <p>Ø6*30MM 6+1PCS</p>
<p>E</p>  <p>M4*30MM 25+2PCS</p>	<p>F</p>  <p>M3.5*12MM 36+2PCS</p>	<p>G</p>  <p>4+1PCS</p>	<p>H</p>  <p>M3*16MM 4+1PCS</p>
<p>I</p>  <p>1PCS</p>	<p>J</p>  <p>6PCS</p>	<p>K</p>  <p>M3*12MM 2PCS</p>	



STEP 1




	A*14PCS		C*17PCS
--	---------	---	---------


STEP 2




	F*18PCS		J1*6PCS
---	---------	---	---------


STEP 3




	B*7PCS
---	--------




STEP 4




	B*7PCS
---	--------




STEP 5




	A*9PCS		B*4PCS		C*4PCS
---	--------	---	--------	---	--------


STEP 6




	A*9PCS		B*4PCS		C*4PCS
---	--------	---	--------	---	--------



STEP 7




	B*5PCS
---	--------




STEP 8




	B*5PCS		E*2PCS
---	--------	---	--------


STEP 9



	A*4PCS		B*4PCS		C*6PCS
---	--------	---	--------	---	--------





STEP 10





	E*8PCS
---	--------



STEP 11

X3





	A*15PCS		D*6PCS
---	---------	---	--------


STEP 12





X2







X2

	E*15PCS
---	---------


STEP 13





STEP 14





STEP 15




	F*18PCS		J2*6PCS
---	---------	---	---------

STEP 16




	G*4PCS		H*4PCS
---	--------	---	--------

STEP 17




STEP 18



THANK YOU!

Contact our friendly
customer service team first for help

①



Email:

furni-service@outlook.com

②



Amazon Message

③



Call or Message:

+1 (909) 960-3666

④



WhatsApp

If you have any questions, please leave the **order No.**
and **related picture** information, we will reply you
within 24 hours, and solve the problem as soon as possible.