


TIME SETTING INSTRUCTIONS:

INSERT ONE "AA" BATTERY (ALKALINE BATTERY RECOMMENDED) IN BATTERY COMPARTMENT. BE SURE THAT THE (—) NEGATIVE AND (+) POSITIVE TERMINALS CORRECTLY MATCH THE SYMBOLS ON THE BATTERY COMPARTMENT.

SET THE CORRECT TIME BY ROTATING THE TIME SETTING KNOB AS SHOWN.




REMOVE THE BATTERY BEFORE STORING THE CLOCK. A WORN OUT BATTERY CAN DAMAGE YOUR CLOCK.

DO NOT DISPOSE OF THIS PRODUCT IN FIRE, BATTERIES MAY EXPLODE OR LEAK.

INSTRUCTIONS POUR RÉGLER L'HEURE :

INSÉREZ UNE PILE « AA » (PILE ALCALINE RECOMMANDÉE) DANS LE COMPARTIMENT DE PILE.) ASSUREZ-VOUS QUE LES BORNES (-) NÉGATIVE ET (+) POSITIVE CORRESPONDENT CORRECTEMENT AUX SYMBOLES SUR LE COMPARTIMENT DE PILE.

RÉGLEZ À LA BONNE HEURE EN TOURNANT LE BOUTON DE RÉGLAGE TEL QU'INDIQUÉ.



RETIREZ LA PILE AVANT DE RANGER L'HORLOGE. UNE PILE USÉE POURRAIT ENDOMMAGER VOTRE HORLOGE.

NE JETEZ PAS CE PRODUIT DANS LE FEU, LES PILES POURRAIENT EXPLOSER OU AVOIR UNE FUITE.