

ASSEMBLY INSTRUCTIONS 4120 GAZEBO



Assembly requires 2 adults and a 10mm spanner (provided)
The gazebo is best assembled close to its intended location.

1. BOX 1 contains the roof section, comprising 1 central roof dome, 4pcs roof sides, and 1 pack containing: 12pcs x 40mm bolts, 8pcs x 30mm bolts and the central finial with fixing plate, plus a 10mm spanner.
2. Bolt together the 4 roof side sections with the (smaller) 30mm bolts through the pre-drilled holes, tightening up with the spanner once fully assembled
3. Attach the finial by removing the nut, placing on top of the roof centre and then threading the plate through from underneath then re-attaching the bolt, tightening up with a spanner.
4. Attach the top roof centre to the assembled bottom roof section, by lining up the predrilled holes and using 4 of the 40mm bolts to secure. Tighten with the spanner.
5. Open BOX 2 containing the 4pcs sides and 4pcs base rings.
6. Turn the roof on its side and attach the top of the sides to the roof using the remaining 8 40mm bolts through the pre drilled holes.
NOTE: Start with the first side piece on the floor and then attach the first part of the base ring and then revolve a quarter turn and then attach the next side on the floor in sequence revolving each time.
7. Ensure all nuts are tightened with the spanner and then raise the gazebo upright into position