
ASSEMBLY INSTRUCTIONS:

- 1. Carefully unpack and lay out the parts as shown in illustration.
- 2. Screw column (A), tube (B), tube (C), socket section (D) to the base (G) in turn.
- 3. Insert the harp (E) to the saddle of the socket section (D).
- 4. Place the shade (not included) onto the harp (E) and screw it tightly by the finial (F). then adjust the shade to be horizontal.
- 5. Install Bulb into the socket and enjoy your new lamp.

Use 3-way 150 Wattage (Maximum) type A bulb for central socket and 3*60 Wattage (Maximum) type A bulb for side sockets (Bulb not included)



IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.