Toddler Toy Storage Cabinet

ASSEMBLY INSTRUCTIONS

Retain the instructions for future ref.

ITEM #K5CC160119

HARDWARE

A.Lockingbolt×16PCS
Have been pre-installed on parts.



6*40mm
*Bolt Sets have been pre-installed on parts.

B.Hex Screw× 15PCS




7*45mm

B.Allen Wrench×1PCS




PARTS LIST

Please carefully check every parts prior to assembly




STEP1: As shown in the diagram below, pay attention to the placement of parts below and attach them.

Place it on the flat floor as shown right, and use 2 Hex Screws B. to attach parts 2 and 5.




STEP2: As shown in the diagram below, pay attention to the placement of parts below and attach them according to the diagram.




REMINDER:

Parts 4 and 5 are trapezoidal. Please refer to the installation diagram to place them in the correct position.
For details, please refer to components X and Y.

Place it on the flat floor as shown above, and use 4 Hex Screws B. to attach parts 1 and 4.




STEP3: As shown in the diagram below, pay attention to the placement of components X and Y below and attach them according to the diagram.



1.Place it on the flat floor as shown above, and use 4 Hex Screws B, to attach components X and Y.


2.As shown in the figure on the right, place the component Z side upright for the next installation step.

STEP4: As shown in the diagram below, pay attention to the placement of component Z below and attach them according to the diagram.




How to use locking bolt A.?

1.Put nut piece into side hole first.
2.Insert the screw and fix with nut.
3.Tighten with a wrench.



1.Place it on the flat floor as shown above, and use 1 Hex Screws B. to attach part 6 and component Z.



2.Use 5 locking bolts A. to attach part 8 and component Z.

CAUTION:

Adult assembly required.
Hardware contains small screws with sharp points.Keep unassembled parts.

MAINTENANCE:

-Placing on flat and level surface while using.
-Ensure the produt continue to function properly and safely by regularly checking the hardware and tightening when necessary.

⚠ WARNING:

Choking Hazard： Small parts
Not for children under 3 years and put it to somewhere children can’t reach.
Appropriate age grade: 36 Months+


Toddler Toy Storage Cabinet

ASSEMBLY INSTRUCTIONS


Retain the instructions for future ref.

ITEM #K5CC160119


STEP5: During this step, the back panel may exhibit slight bending. Please ensure to adjust it flat before inserting it into the back panel groove.



As shown in the figure above, embed the 2 parts 10 into the part 11, and then insert them into the groove of part 1.





Then forcefully push the whole back panel composed of parts 10 and part 11 to the left into the groove of part 8.




Place part 3 as shown in the figure above, and then use 2 Hex Screws B. and 2 locking bolts A. to fix.

STEP6: As shown in the diagram below, pay attention to the placement of parts below and attach them.







1.As shown in the diagram above, use 1 Hex Screw B. and 1 locking bolt A. to fix part 7 and part 12.

2.Use 1 Hex Screw B. and 8 locking bolts A. to fix the rest part 9.

3.For the above installation steps, we recommend that two adults cooperate to carry out the installation.

REMINDER:

Since the back panel parts are relatively thin, they may exhibit slight bending before being fitted into the back panel grooves. This is not a quality issue. You simply need to gently adjust the back panels until they are straight and then insert them into the surrounding grooves to resolve the problem.

Reminder: If you have any issues with the product please e-mail us for support at **scg4586@yeah.net.**

IMPORTANT INFORMATION-PLEASE READ FIRST:

ALL OF OUR WOOEDN ITEMS ARE HANDCRAFTED,HAND ASSEMBLED,AND HAND PAINTED.EACH ONE IS UNIQUE.SLIGHT INPERFECTIONS MAY OCCUR AND ARE NOT MANUFACTURING DEFECTS.EACH ITEM HAS BEEN PAINTED WITH VERY DURABLE PAINT THAT IS BOTH LEAD AND CHROMATE FREE AND SAFE FOR CHILDREN.HOWEVER,IT WILL NOT WITHSTAND ABNORMAL ABUSE AND WITH IMPROPER USE,IT COULD CHIP.

PLEASE NOTE THAT WE DO NOT WARRANTY AGAINST THE USE OF PERMANENT MARKERS,NON-WATER-BASED PAINTS,CRAYONS,OR WASHABLE MARKERS.SOME OF THESE ITEMS CONTAIN PERMANENT COLOR DYES THAT COULD DAMAGE THE SURFACE.

CLEANING INSTRUCTIONS

CLEAN THE SURFACE USING A SLIGHTLY DAMP CLOTH AND MILD DISH WASHING LIQUID IF NECESSARY.DO NOT USE ANY CLEANING PRODUCT CONTAINING ALCOHOL OR AMMONIA.THESE WILL DULL THE SHINY SURFACE OF THE PRODUCT.FURNITURE POLISH WILL ALSO WORK TO CLEAN AND DUST OFF THE SURFACE.

WARRANTY

IMPORTANT:EVIDENCE OF ORIGINAL PURCHASE IS REQUIRED FOR WARRANTY SERVICE.

LENGTH OF WARRANTY:90 DAYS FROM DATE OF PURCHASE.

THIS WARRANTY COVERS EDFECTS THAT WERE A RESULT OF THE MANUFACTURERS PRODUCTIONS.YOU SHOULD CAREFULLY INSPECT THE CONDITION OF THE PRODUCT PRIOR TO ASSEMBLY.THIS WARRANTY IS INVALID IF THE PRODUCT IS DAMAGED OR NOT MAINTAINED PROPERLY.

Development zone of Heilin Ganyu section Lianyungang Jiangsu Pov.China.
Powered by lianyungang yubao I/E CO.,LTD
Kids Furniture Research And Development.
K.R.A.N.D.