



Assembly Instructions



Caution: You must read this before you proceed

Power Reclining Chair




Parts List




Label	Picture	Description	QTY
A		Chair Base with Footrest	1
B		Chair Backrest	1

C		Left Wing (Labelled C)	1
D		Right Wing (Labelled D)	1

Hardware

Label	Picture	Description	QTY
①		Power Line with Transformer	1

Assembly Preparation

<p>Before Beginning Assembly:</p>	  
---	---



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Power Recliner Chair has multiple parts and may require about 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Remove the Chair Backrest(B) from the Chair Base with Footrest(A).

Step 2




Take out the small carton box from the back of Chair Base with Footrest(A) containing the Power Line with Transformer(①).

Step 3




Take out the 2 non-woven bags with the Left Wing(C) and Right Wing(D) from the bottom of Chair Base with Footrest(A).

Step 4




With assistance from your adult partner, hold up the Chair Backrest(B) while standing behind the Chair Base with Footrest(A). Insert the small metal arms on the sides of the Chair Backrest(B) into the prefabricated slide lock gadget on the Chair Base with Footrest(A) as shown above. Firmly but gently, push the Chair Backrest(B) downwards until the Backrest is fully slotted and locked into position.

Step 5




Align the mounting brackets of the Left Wing(C) with those on the left side of Chair Backrest(B). Then slide Left Wing(C) downward by hand to make sure it locks into the position as shown in the picture. Repeat the same process to attach Right Wing(D) to the right side of Chair Backrest(B).

Step 6




Smooth down the fabric flap on the Chair Backrest(B).
Run your hands down both sides of the flap, from top to bottom, allowing the velcro tape to adhere to the flap under the seat of the Chair.

Step 7



Locate the power interface line at the bottom of Chair Base with Footrest(A).
Connect the power interface and Power Line with Transformer(1), then fasten the buckle as pictured above.

Step 8




Make sure all parts are connected and securely locked into position.
Your Power Recliner Chair is ready for use.

This Power Recliner Chair can only be used on a flat, level surface.


To Disassemble Recliner

Step 9



Push up on the Right Wing(D) and Left Wing(C) one by one until removed from the Chair Backrest(B).

Step 10




To Disassemble Recliner:

Open the flap on the Backrest(B), use a screwdriver (Don't use your fingers) pressing outward on the metal ear on the preattached Metal Bracket on one side of the Chair Base(A).


With assistance of your adult partner to keep the Chair Base(A) in place, pull the Backrest(B) upward at the same time, repeat the same step for another side.

Step 11



Open buckle, then pull apart power interface from Power Line with Transformer(①).

Warning



Do not allow children to play on the Recliner.
Always leave the Recliner in an upright and closed position after use.
Keep hands and feet clear of the footrest mechanism and any gaps.
Don't sit any armrest of Recliner.

User Instructions


Power Recliner Chair

To get into the Recline position:


Sit into the seat.

Press the Front button on the switch on the outside of right armrest.


The Power Recliner Chair will smoothly descend into a fully reclined position.



Press the Front button to Open
USB Charger




Switch




To move the Chair back into the Upright Position:

Press the Hind button on the switch on the outside of right armrest.

The Power Recliner Chair will smoothly ascend until fully into an upright position.



Press the Hind button to Close
USB Charger



Switch



Care & Maintenance

-   ● Do not put hot items directly on furniture surface
 -   ● Do not clean furniture with harsh cleansers or polish.
 -   ● Do not place furniture under direct sunlight.
 -   ● Do not place furniture near heating or cooling vents.
 -   ● Do not write on furniture without a padded barrier to protect the surface.
 -   ● Do not place furniture outside . For indoor use only .
 -   ● Not for commercial use. For residential use only .
 -   ● Stains may be removed with mild soap solution and damp cloth.
 -   ● Children should not climb or jump on the furniture.
-
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .

Questions & Answers about Proposition 65

• What is Proposition 65?

Proposition 65 requires businesses to provide warnings to Californians about significant exposures to chemicals that cause cancer, birth defects or other reproductive harm. These chemicals can be in the products that Californians purchase, in their homes or workplaces, or that are released into the environment. By requiring that this information be provided, Proposition 65 enables Californians to make informed decisions about their exposures to these chemicals.

Proposition 65 also prohibits California businesses from knowingly discharging significant amounts of listed chemicals into sources of drinking water.

Proposition 65 requires California to publish a list of chemicals known to cause cancer, birth defects or other reproductive harm. This list, which must be updated at least once a year, has grown to include approximately 900 chemicals since it was first published in 1987.

• What types of chemicals are on the Proposition 65 list?

The list contains a wide range of naturally occurring and synthetic chemicals that include additives or ingredients in pesticides, common household products, food, drugs, dyes, or solvents. Listed chemicals may also be used in manufacturing and construction, or they may be byproducts of chemical processes, such as motor vehicle exhaust.

• What does a warning mean?

If a warning is placed on a product label or posted or distributed at a workplace, a business, or in rental housing, the business issuing the warning is aware or believes that it is exposing individuals to one or more listed chemicals.

By law, a warning must be given for listed chemicals unless the exposure is low enough to pose no significant risk of cancer or is significantly below levels observed to cause birth defects or other reproductive harm.

• Where can I get more information on Proposition 65?

If you have specific questions on the administration or implementation of Proposition 65, you can contact OEHHA's Proposition 65 program at P65.Questions@oehha.ca.gov, or by phone at (916) 445-6900.