Lighted Red Ribbon Bow



Illustrated assembly guide

MODEL XD7582

Finished dimensions
24 in L x 2.36 in W x 31.5 in H

Keep the power disconnected while joining the frame and light connections. Use the supplied power source for your item.

Before you begin

Arrange the components on a clean surface. Upper bow section, two ribbon tails, LED cord connections, power adaptor and zip ties.



Have scissors ready when zip ties are used. Cut only excess tie ends; keep scissors clear of the light wires.

Assembly sequence

Follow the numbered steps. Check each frame and cord connection before applying power.

1 Secure the first ribbon tail



Turn the pieces over. Align one tail with the upper bow frame and secure the joining frames with zip ties.

2 Attach the second tail



Repeat on the other side. Check that both tails are secure, then trim excess zip-tie ends clear of the light wires.

3 Connect the LED cord



Join the matching LED cord connectors and check that the connections are secure.

4 Check and illuminate



Confirm the bow is securely assembled. Position it for display, connect the supplied adaptor, and check the lights.

Warranty?
Troubleshooting?

Scan the QR code for
instructions, support, & registration.

XProductSupport.com/product/XD7582

Instructions, support & warranty

Scan the mini card or click below to:

Watch the instructional video
Create a support ticket
Register your item for warranty

XProductSupport.com/product/XD7582