

INSTRUCTION MANUAL

11FT x 11FT Gazebo
























Series E15

IF YOU PURCHASED THE GAZEBO ONLINE AND HAVE ANY
QUESTIONS OR CONCERNS
PLEASE CONTACT US WITH EMAIL OR TEXT

Email: service2outdoor@gmail.com

Text: +1 628 263 4608

Lost accessories or parts costs will be incurred after 90 days
of the date of purchase.



<1>


A 4x



J 4x




J1 4x




1 16x




M6x15





(B1) 4x



(B2) 4x



M6x15


(1) 24x




M6x35


(2) 8x

<2>





(C1) 4x




(C2) 4x



M6x35

(2) 32x


<3>




5




(D) 8x



(E) 4x



(F) 16x






(1) 8x
M6x15



(3) 16x
M6x25

<4>





(H1) 4x



(H2) 4x




(K) 1x



(I) 1x

<5>



7




(H3) 4x



M6x15

(1) 4x

<6>







(M1) 1x



(M2) 1x

<7>






(M3) 1x



(G) 48x



(4) 8x

<8>

