

# Assembly Instructions

ITEM NO. D 4832-40

POTOMAC SERVER




Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the PARTS LIST and/or HARDWARE LIST shown below.







Please read the instructions thoroughly before assembly.

1. We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
2. Please do not tighten screws or bolts until the assembly is completed.
3. To level the chairs or table, before tightening all the screws, the chairs or table must be placed on a flat surface and then tighten the screws.
4. Please put all parts on a non-abrasive floor before assembly and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

## PARTS LIST


NO.	COMPONENT	SKETCHQTY.	QTY.
A	TOP		1 PC
B	CASE		1 PC
C	LEGS		4 PCS

## HARDWARE LIST

NO.	COMPONENT	SKETCHQTY.	QTY.
1	FLAT WASHER 5/16 *DIA		12 PCS
2	LOCK WASHER 5/16 *DIA		12 PCS
3	BOLT 5/16 *2-3/8"		12 PCS
4	ALLEN KEY 3/16*2-1/8"		1 PC

To assemble the bench, please follow the following steps:

STEP 1: Assemble the legs




## Assembly Instructions

ITEM NO. D 4832-40

POTOMAC SERVER

STEP 2: Attach the top together with the base



Attention : Do not over tighten the bolt