


ASSEMBLY INSTRUCTIONS

Not Provided


Kitchen Cart

Two persons for assembly




Hardware List							
A	M6 x40mm = 6	G	= 4	M	7/8" = 4	Q	= 2
B	M6 x 50mm=14	H	20mm = 4			Caster with Lock - 50mm	
C	1/4" = 4	I	M3.5 x16mm=32	N	#8x 1 1/4" = 8	R	= 2
D	M6 x13mm= 4	J	= 4	O	14.5Ø = 7	Caster without Lock - 50mm	
E	M6 x13mm=14	K	9mm = 8	P	9Ø X 350mm = 4		
F	= 1	L	24mm = 8				


1




2




3




4




5




6




7



8





9





Adjust the hinge to make the door even



10



11



12



Thank you for purchasing our product!

Please assemble the products with the guidance of this manual instruction . Contact our friendly customer service department with any or comments or in case there is any missing or damaged parts or hardware. Replacements for missing or damaged parts or hardware are normally shipped within 2 to 3 days.

We appreciate your business!