










ASSEMBLY INSTRUCTIONS


SERVER

A Server	B Leg	C JCBC Bolt M6 x 40mm	D Spring Washer M8 x 13mm
			
1 pc	2 pcs	10 pcs	10 pcs
E Flat Washer M8 x 18mm	F Wood Screw M4 x 32mm	G Allen Key M4	H Anti-Tip Kit
			
10 pcs	4 pcs	1 pc	1 bag




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

- 1** Place the Server (A) on a protective surface.
- (i) Attach the Leg (B) to the Server (A) using JCBC Bolt (C), Spring Washer (D) and Flat Washer (E) with the Allen Key (G).
 - (ii) Secure the Leg (B) using Wood Screw (F) with a screwdriver (not provided).



2

PARTS IDENTIFICATION




HARDWARE IDENTIFICATION

#A		STRAP	1 PC
#B		BRACKET	2 PCS
#C		SCREW M4x16mm	1 PC
#D		SCREW M4x45mm	1 PC

This Anti-Tip Kit (H) must be attached to a wall stud using the Screw (#D) enclosed.

1. Attach a Bracket (#B) securely to the back top rail of the Server (#1) using the Screw (#C) provided through the smaller hole.
2. Locate the other Bracket (#B) on the wall over a wall stud and 45mm below the mounting bracket secured to the back of your unit. Attach it to the wall stud using the Screw (#D) provided through the smaller hole.
3. Place the furniture into position so both mounting Bracket (#B) are vertically in line.
4. Lace the end of the restraint Strap (#A) through the larger hole in each mounting bracket.
5. Confirm that the Strap (#A) is securely laced and locked.



NOTE / REMARQUE

The Anti-Tip Kit is included in this product. Please refer to the installation instructions in the hardware pack.

Une trousse anti-bascullement est fourni avec ce produit. Veuillez vous référer aux instructions d'installation dans inclu dans la trousse de quincaillerie.

*THE ANTI-TIP KIT IS LOCATED ON THE BACK PANEL.

*UNE TROUSSE ANTI-BASCULEMENT EST SITUÉ SUR LE PANNEAU ARRIÈRE.

Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.