




1. Thank you for choosing *our products*.

Recommendations Before Beginning Assembly



- Read instructions, cover to cover



- Have 2-4 adults on hand for assembly [depending on product size](#)



- Do not assemble [directly](#) on flooring or carpet



- Assemble on a clean non-marring surface ([example](#): packing foam)



- Save all packaging until finished

3. Assembly Notice:

- If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the parts of the product stored in a safe place and contact us immediately so we may assist you further.
- Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the

hardware spill in the box.

- Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- **IMPORTANT:** When setting up your product, **DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING.** Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.

Care & Maintenance



Do not put hot items directly on furniture surface



Do not clean furniture with harsh cleansers or polish



Do not place furniture under direct sunlight



Do not place furniture near heating or cooling vents



Do not write on furniture without a padded barrier to protect the surface



Do not place furniture outside. For indoor use only



Not for commercial use. For residential use only



Stains may be removed with mild soap solution and damp cloth




Children should not climb or jump on the furniture










Dust and pick-up spills using a clean, non-colored, lint-free cloth

Caution



- This product contains small components. Please ensure that they are kept away from small children.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.







				
Ø6x35mm	Ø15x12mm	Ø6x30mm	Ø5x50mm	
AX10	BX10	CX12	DX2	EX1
	 Ø3x14mm			 Ø6x30mm
FX8	GX8	HX8	IX4	JX8
		 Ø4x16mm	 x2    	
KX4	LX4	MX48	NX1	

STEP 1




		
AX4	Ø6x30mm CX4	EX1



STEP 2





STEP 3





STEP 4




STEP 5



STEP 6





STEP 7




IX2	JX4	MX8	LX4

STEP 8



NOTE: If the doors are uneven or there is a gap in the middle, loosen or tighten the screw on the door hinge until they are sitting flush.




Ø 4x16mm

MX16


STEP 9

X2






KX4	Ø 4x16mm	IX2	Ø4x22mm

STEP 10





STEP 11



		 x2		
FX8	GX8	N1	N2	N4

STEP 12




STEP 13

Assembly Steps(EN) / Montageschritte(DE)

HOW TO ADJUST THE HINGES TO ALIGN THE DOORS IF NEEDED.


STEP 1

Open the door.




STEP 2

Adjust the door panels up or down



STEP 3

Adjust the flush between door panel and side panel



STEP 4

Adjust the Gap between door panel and side panel

