


Assembly Instruction

Note:


- 1. Should be assembled on flat ground to keep balance.**
- 2. Before completing the installation, do not tighten the screws.**



It needs at least two people to install.



Before starting the assembly, you must read the whole manual and follow the instructions.



Assembly Instruction

Hardware parts



Ⓐ M8*20
32PCS



Ⓑ M8x35
4pcs




Ⓒ M8x45
5pcs



Ⓓ 4#
1pc

Part list




① 1 PC




② 2 PCS




③ 1 PC



④ 1 PC




⑤ 2 PCS



⑥ 2 PCS




⑦ 2 PCS




⑧ 1 PC



⑨ 2 PCS



⑩ 1 PC




⑪ 2 PCS




⑫ 4 PCS

Assembly Instruction

C	 M8x45	4pc
D		1pc




A	 M8x20	2pc
D		1pc



Assembly Instruction


A	 M8x20	8 pcs
D	 4 #	1 pc



Note: Place Part 5 and Part 6 with their wider-spaced holes at both ends together before installing Part 7.

A	 M8x20	8 pcs
D	 4 #	1 pc


Note: When installing, keep this notch facing upwards.




Note: When installing, keep this notch facing upwards.

Assembly Instruction

A	 M8x20	4pcs
D		1pc




A	 M8x20	4pcs
D		1pc




Assembly Instruction

B	 M8x35	2pcs
C	 M8x45	1pc
D		1pc



A	 M8x20	4pcs
B	 M8x35	2pcs
D		1pc



Assembly Instruction

