

ASSEMBLY INSTRUCTIONS


V-WD26-1401

PF056




WARNING !





Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.

Make sure no parts are missing or damaged before assembly.

PACKAGE CONTENT


Board Identification

Not actual size




BOARD IDENTIFICATION


Not actual size




① x1




② x2




③ x2




④ x1




⑤ x1




⑥ x1




⑦ x1




⑧ x6




⑨ x6




⑩ x6




⑪ x6




⑫ x6




⑬ x4



⑭ x1




⑮ x1




⑯ x1

BOARD IDENTIFICATION


Not actual size




⑰ x1



⑱ x4




⑲ x1




⑳ x1

HARDWARE LIST




A	x62+2



Ø15x9.5

B	x62+2




Ø6x30

C	x43+2




Ø4x32

D	x33+1




Ø3.5x12

E	x72+2




Ø3x15

F	x8



G	x2




H	x1




Ø5x48


I	x4+1




CL	x6



CR	x6




DL	x6



DR	x6


Cam Lock Fastening System


Insert the cam bolt into the hole first, then insert the cam lock and lock it.




STEP 1


PF056








STEP 2







STEP 3

PF056













Ø3.5x12	
E	x 18





CL	x 3





CR	x 3

STEP 4










A	x 10

STEP 5


PF056



Ø6x30	
C	x 2

Ø4x32	
D	x 2

STEP 6




Ø6x30	
C	x 1

Ø4x32	
D	x 1

STEP 7


PF056




Ø6x30	
C	x 2

Ø15x9.5	
B	x 2

STEP 8







Ø6x30	
C	x 5

Ø15x9.5	
B	x 5

STEP 9

PF056







Ø6x30	
C	x 2

Ø15x9.5	
B	x 2

STEP 10






Ø6x30	
C	x 5

Ø15x9.5	
B	x 5

STEP 11


PF056



Ø6x30	
C	x 4


Ø5x48	
I	x 4


STEP 12




STEP 13


PF056






STEP 14









STEP 15

PF056







Ø6x30	
C	x 8

Ø15x9.5	
B	x 8

STEP 16







Ø6x30	
C	x 8

Ø15x9.5	
B	x 6


STEP 17


PF056






STEP 18







STEP 19





STEP 20







STEP 21












STEP 22






X4



STEP 23

PF056




Ø3.5x12		
E	x 12	

DR	x 2

DL	x 2

STEP 24




Ø3.5x12		
E	x 24	


DR	x 4

DL	x 4

STEP 25


PF056






STEP 26


PF056






G

STEP 27






G

STEP 28

PF056



bx2	ex2
G	

FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

· Tighten all bolts and screws again within the first 2 weeks of assembly
· Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

· Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
· Small amount of mild soap can be used if necessary
- **Dry the surface immediately after cleaning.**

⚠ DO NOT use bleach or alcohol detergent to clean the surface.
⚠ DO NOT apply wood treatment on parts made with MDF and PB.
Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.
Make sure to dry the furniture immediately after cleaning