


Website : www.x-cosrack.com

E-mail : info@x-cosrack.com


Facebook: www.facebook.com/cosrackofficial/

Assembly Instructions

Parts Included




2pcs
A




2pcs
B




6pcs
C



1pc
D




2pcs
E



3pcs
F




2pcs
G




12+2pcs

1



4+1pcs

2




4pcs

3



1pc



4





1pc

5





1. Use screws ② to fix parts A to the corresponding holes of parts B.
And then rotate the bottom feet into the corresponding holes of parts B.




2. Use screws ① to fix the parts C to the corresponding holes of part AB.




3. Open 1D and 2E and place F at their bottom.



4. Insert 1D and 2E into 6 iron pipes C.



5. Use screws ① to fasten the part AB to the corresponding hole of iron pipes C.



6. Two separators G are stuck in storage bin D and then finish all.

