

















EAST BANK[®] DESIGNS

DESIGNED TO SIMPLIFY,
CRAFTED TO LAST.

www.adhomegoods.com

Ax2 	Bx2 	Cx2 	Dx1 	Ex1 	Fx1 	Gx4 			
						Hx4 			
Ix4 	Jx2 	Kx4 	Lx4 	Mx4 	Nx1 	Ox1 	Px2 	Qx2 	Rx1 





EAST BANK[®] DESIGNS

DESIGNED TO SIMPLIFY,
CRAFTED TO LAST.



9-748-BK & 9-748-WH

We suggest you lay all parts out and read through the entire directions before you start.



WARNING

- Do not let any sharp objects touch or rub the surface of the product.
- When assembling, do not let children play around the working area.
- Please confirm all parts are correct before starting the assembly process.
- Do not tighten bolts and screws completely until the entire unit has been assembled and set up.
- DO NOT USE POWER TOOLS. Power tools can overtighten screws and strip threads.

• For each screw:

1. Tighten each screw until you meet resistance.
2. Tighten one additional full rotation. DO NOT OVERTIGHTEN.



THANK YOU FOR YOUR PURCHASE.

If you have any problems please contact customer service for help, we are happy to make it right!

Customer Service:

admin@adhomegoods.com
www.adhomegoods.com