

Portable Sauna Steam Pot

User Manual



Safety Instructions

1. Please keep the appliance in balance when using it. To prevent fire hazard, avoid placing the sauna steam pot near flammable materials.
2. Pregnant women and people having high blood pressure and heart disease should not use this product. Please wait at least 30 minutes after eating before using this product. Do not use this product in time of great hunger for your safety.
3. When using the product, stay at least 10cm away from the steam pores. Don't touch the steam pores with bare hand.
4. Don not use the product in humid environment or immerse it into water.
5. The water filled in the sauna steam pot should not reach over the max water line in case of malfunction.
6. User should drink 200 – 300 ml water or tea before using the product. Please prepare a towel for wiping sweat. Take a break after a certain period of using. Don't use the product consecutively over 20 minutes in one time.
7. Old people should be accompanied by their families when using the product.
8. The steamer will power off automatically when the water inside dries up. It will restart 20 minutes later. If it doesn't restart, please contact supplier. Never turn on the steamer without water added.
9. Don't forget to disconnect the power after use and wipe it clean with a damp cloth after 10 minutes of cooling down. Don't clean the product with water directly.
10. The sauna room and steamer must be placed at a flat surface. If the steamer doesn't work, don't open the lid immediately. Disconnect the power and let it thoroughly cool down first.
11. Always keep the product clean and in good condition as it would make its service life longer.
12. Keep the product out of reach of children.

- 13. Flammable, toxic, corrosive or other harmful liquid must not be put into the steamer as it might cause bodily injuries or property damage.
- 14. The steamer should be only used with the sauna room. It should not be used for other heating purposes. Don't repair or modify the product by yourself as it will invalidate the warranty.

Package Contents



Sauna Steam Pot x 1



Remote Control x 1



Steam Box x 1



Steam Tube x 2


Specifications

Rated Voltage	110 V; 60 Hz
Rate Power	800 W
Overall Dimensions (L x W x H)	8" x 8" x 10" (20 x 20 x 26 cm)

Set up the Sauna Steam Pot

Note: The sauna tent shown in the following steps is for illustrative purpose only. It is not included in this product. Customer needs to buy it separately.

1




The lid of sauna steam pot is installed conversely when it left the factory. Please take it out and turn it around. After that, put it back on the sauna steam pot.

2




Use one of the steam tubes to connect the sauna steam pot and the inlet hole on the outer side of the sauna tent. Make sure the steam tube is well connected with the two parts. If the steam tube falls off or loosens during usage, please turn off the power and let it thoroughly cool down first before reconnection.

3





Use the other steam tube to connect the steam box and the outlet hole on the inner side of the sauna tent. Make sure the steam tube is well connected with the two parts. If the steam tube falls off or loosens during usage, please turn off the power and let it thoroughly cool down first before reconnection.



Caution:

When you are using the product, please make sure all of the steam tubes are not bent as shown in the right picture since it would block the flow of steam. As results, it may make the steam tubes pop off and hot steam stray out, causing scalding and other bodily injuries. Make sure the steam tubes are placed straight. If you find they are bent, turn off the power and let them thoroughly cool down first before you adjust their positions.

Operation Instructions



Sauna Steam Pot Operation Panel

You can operate the sauna steam pot with the remote control or the operation panel on the steam pot itself. The specific operation instructions are as follow:

1. Connect the power cord of sauna steam pot to a power outlet.
2. Add water to the steam pot. **(The water filled in the sauna steam pot should not reach over the max water line in case of malfunction.)**
3. Press the power button on the remote control or the steam pot operation panel to turn on the steam pot.
4. We recommend you to press the temp button on the remote control or the steam pot operation panel to P9 first to let the appliance preheat for 7- 10 minutes.
5. After the preheating is finished, adjust the temperature back to P5 as P5 is suitable for most people. You can turn it up if you think it is not hot enough. Besides, you can press the timer button to set the auto-turn-off time.
6. **After use, remember to disconnect the power and let the product thoroughly cool down first before you disassemble the tubes and other parts.**