Christmas tree



Product Installation Notes

Specification

IMPORTANT SAFETY NOTICE: READ CAREFULLY BEFORE BEGINNING ASSEMBLY!

※ Always use proper tools.

※Follow the assembly steps in order. Do not skip any steps.

※Be sure to check all packing materials carefully for small parts may have come loose inside thecarton during shipment. If parts are missing, contact the retailer from which you purchased theproduct to obtain any missing parts. DO NOT USE SUBSTITUTE PARTS.

※Periodically check to ensure that all connectors (bolts, screws, etc.) aretight.Keep the instructions for future reference.

※Some assembly may involve attaching glass or mirrors. Be very careful handling the glass ormirrors, as severe injury may result if the glass or mirror breaks. Never handle large pieces ofglass or mirrors by yourself.

※When assembling products that have electric cords (lamps, lights, etc.), always (1) make surethe electrical cord is unplugged before assembly and (2) be careful not to twist the electricalcordduring assembly.

※When assembling shelves or entertainment centers, do not stand on lower shelves in ordertoassemble upper shelves—use a step ladder.

※ Do not stand on tables, including but not limited to, end tables, coffee tables, and dinnertables,as tables are not meant to support the weight of a person.

※Where assembly instructions state that assembly requires two or more people, do not attempt assembly by yourself as there is a risk of injury.

NOTE: YOUR UNIT MAY LOOK DIFFERENT IN APPEARANCE FROM THE ONE SHOWN IN THE ILLUSTRATIONS ON THIS INSTRUCTION SHEET.

PRODUCT INTRODUCTION

Specification

Product Name	Christmas tree
Model / SPU	Christmas tree lights
Product Size	See packaging information for details.
Weight	See packaging information for details.

Componets



SAFETY WARNINGS

Safety Definitions

IMPORTANT SAFETY INFORMATION

Please carefully read theinstructions and caution warnings below before assembling theproduct.Following this guide will ensure that you install, use and maintainthe product properly.

※Please keep this installation and user manual/instructions for futurereference in case you need to assemble the product.
※Do not assemble if you notice serious damage such as cracks or bends.
※During installation, please use work gloves for hand safety.
※Please assemble the unit on carpeted floor or the flat cardboard box toavoid scratching the surface or your floor while assembling on the floor.
※To assemble, please use the complimentary installation tools (AllenWrench). Pay more attention to the direction of components at eachsteps.
※It is recommended that two people work together to assemble theproduct.
※Please do not tighten the screws up too much, just to 80% before youfinish to make the installation go on successfully.

RETURN POLICY

We believe you will absolutely love your new product.But for some reason you want to return your item, please contact uswithin 30 days after receiving and ensure that the product which you wantto return is in a good condition in the original box with all originalcertificates of purchase, manuals and accessories attached.

HOW TO MAINTAIN YOUR PRODUCT:

※Check the screws of the product are not loose from regular use.
※Do not use sharp instruments, rubbing alcohol, corrosive chemicals, orabrasive cleaners to clean the product.
※Do not keep the product in a damp environment for a long period of time. The damp environment may cause the iron components to rust and theplates to bulge and crack.

INSTALLATION

Parts List

1

Take the Christmas tree out of the box



2

Remove the protective packaging of the Christmas tree




3

Unscrew the screws




4

Install the batteries



5

Refit the screws



6

Shape and adjust the Christmas tree branches



7

Turn on the switch



8

Display the lighting effect



Troubleshooting

Lights not working:

1.Check if the batteries have power.

2.Unplug the power cord of the light box and check the connection.

3.Check if the product switch works properly.

Poor tree shape :

1. Make sure all branches are fully spread out.

2. Check for fallen branches.

Contact customer service for guidance to shape the perfect Christmas tree.