ASSEMBLY INSTRUCTION

ITEM : WF309738

DINING TABLE



ASSEMBLY INSTRUCTION

ITEM : WF309738


DINING TABLE

IMPORTANT NOTE:

Please read these instructions fully before starting assembly:


- 1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
- 2. Kindly follow the assembly instructions step by step.
- 3. Do not tighten all screws and bolts until the table is fully assembled.
- 4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
- Parts of the assembly will be easier with 2 people.
 Care and maintenance:

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.




Part List For One				Hardware List For One				
No	Parts Description.		Q'ty	No	Hardware Description.			
А	TOP PANEL		1pc	1	Bolts 5/16"* 60mm		16pcs	
В	LFAF		1pc	2	Bolts 5/16"* 40mm		8pcs	
С	MOUNTING PLATE		1pc	3	Bolts 5/16"* 30mm	())))))))))	2pcs	
D	BOTTOM LEGS		1pc	4	Spring Washer 5/16"* 13mm x 1.5mm	Ø	26pcs	
Е	BOTTOM LEGS		1pcs	5	Flat Washer 5/16"* 16mm x 1.5mm	0	26pcs	
F	LEGS		4pcs	6	Allen Key	•		
G	MIDDLE LEGS		1рс		4mm*60mm		1рс	
Н	MIDDLE LEGS		1рс					
		-					,	

STEP 1



3x1 4x1 5x1 6x1 1x8 4x8 5x8 6x1	Bolts 5/16 x 30mm	5/16 x 13mm x 1.5mm	0		Bolts 5/16 x 60mm	5/16 x 13mm x 1.5mm	0	Allen Key 4mm x 60mm
	3x 1	(4)x 1	(5)x 1	6x 1	①x 8	(4)x 8	(5)x 8	<u>(6)</u> х 1

3/5



Bolts 5/16 x 40mm	Spring Washer 5/16 x 13mm x 1.5mm	Flat Washer 5/16 x 16mm x 1.5mm	Allen Key 4mm x 60mm
Omm	ø	0	
②x 4	(4)x 4	(5)x 4	6 x 1



