


DRUM PENDANT CEILING LIGHT

ASSEMBLY INSTRUCTIONS


REMOVE ALL PARTS FROM PACKAGE, BE CAREFUL NOT
TO DAMAGE ANY COMPONENTS.



PROFESSIONAL INSTALLATION RECOMMENDED

DRUM PENDANT CEILING LIGHT

REMOVE ALL PARTS FROM PACKAGE, BE CAREFUL NOT TO DAMAGE ANY COMPONENTS.



1. Measure area and determine desired hanging height.

2. Adjust the length of the cord by loosening the screw on the stem of the canopy [D] with the provided screwdriver [A]. Re-tighten screw after desired cord length is achieved.



3. Detach mounting plate [C] from canopy [D].

4. Remove diffuser [F] from product [B]. Remove from plastic bag and re-insert diffuser [F], shiny side down, through bottom of light by angling diffuser [F] and adjusting so it is flat.

5. Install bulb 60W max (not included).

6. Mounting plate [C] will attach to ceiling junction box.

7. Install light to ceiling. We recommend installation by a qualified electrical professional. Canopy nuts [E] are used to tighten light to ceiling. Remove plastic overwrap from shade before lighting.



Note: Turn off switch before replacing the bulb. Make sure the bulb has sufficient time to cool down. Do not subject the lamp to any shock while lit as shattering of glass shade may result.