




INSTALLATION MANUAL

Wall Mounted Fan with Lights




-  Pair button. Click it within 5 seconds after the fan is powered on from wall switch. After the fan flashes or beeps, it has been successfully paired with the phone, it can be controlled through it.
-  Slide to change the fan speed.
-  Slide to change the brightness of the light.
-  Quick switch for "White" light color.
-  Quick switch for "Yellow" light color.
-  Quick switch for "Natural" light color.
-  Night mode, dim the lights.
-  Fan moves forwards.
-  Change the direction of the wind (Not applicable on this fan).
-  Timing the fan.
-  Natural wind: fan speed will change automatically when use this function.
-  Sleeping wind (Not applicable on this fan).
-  Fan moves reversely.
-  Turn on/off the light.
-  Turn on/off the fan.
-  Unpair button. Click it within 5 seconds after the fan is powered on. After the fan flashes or beeps, it has been successfully unpaired with the phone.




TOOLS REQUIRED




Ladder



Pliers



Wire Strippers




Screwdrivers



Power Drill

PACKING LIST





INSTALLATION KIT

AA		2×	BB		2×	CC		2×	DD		2×
	Plum blossom lock			Wood Screw			Flat Washer			Anchor Bolt	
EE		2×	FF		2×	GG		1×	HH		1×
	Remote Holder Anchor			Remote Holder Screw			Remote Holder			Remote Control	
II											1×
											Glove


NOTE:
Some extra hardware may be included. The quantity listed above is the number required for installation.

INSTALLATION


1. Installation Diagram for Cement Wall Surface




Step 1: First fix the bracket position, then drill the holes.




Step 2: Insert expansion anchor (1) into the hole. Note: Do not remove hex nut (4), spring washer (3), and metal washer (2).



Step 3: Tighten hex nut (4) until expansion anchor (1) feels secure and no longer loose.




Step 4: Remove hex nut (4), spring washer (3), metal washer (2) for use in the next step.



Step 5: At last insert the hole on arc-shaped hanger (A) into expansion anchor (1); Successively fit in metal washer (2), spring washer (3), and tighten with hex nut (4).


2. Installation Diagram for Solid Wood Wall Paneling



- Step 1:** Adhere arc-shaped hanger (A) to the corresponding wooden wall.
- Step 2:** Thread wood screw (BB) through flat washer (CC) and tighten arc-shaped hanger (A).


3. Install Arc-shaped Hanger

Align the holes of fixture body (B) with arc-shaped hanger (A) and close them together, then secure with plum blossom lock (AA).




4. Adjustable from Multiple Angles

Loosen plum blossom lock (AA) to adjust fixture body (B) up and down, align it to the desired angle, and then tighten plum blossom lock (AA).




5. Power On and Use




6. Adjustable from Multiple Angles


Adjust the view



7. DIY Installation




REMOTE CONTROL INSTRUCTIONS



- NOTE:**
Please insert 2 batteries before using.
AAA 1.5V battery x 2pcs (not included)
- ① : All off.
 - ② : 1-6 fan speed.
 - ③④ : Adjust the light color temperature.
 - ⑤⑫ : Timing the fan.
 - ⑥ : Fan moves forwards or reversely.
 - ⑦ : Stop the fan.
 - ⑧ : Quick switch of the light color: Yellow Light → White Light → Natural Light.
 - ⑨⑩ : Adjust the brightness of the light.
 - ⑪ : Turn on/off the light.

REMOTE SIGNAL PAIRING:
If the remote control loses the signal of the fan, turn off the power from wall switch, then turn it on, press ⑧ immediately for around 3 seconds, after the fixture beeps or flashes, then it's down.



- Step 1:** Insert 2 batteries before using: AAA 1.5V battery x 2pcs (not included)
Step 2: Install the remote holder onto the wall with screws.