



ASSEMBLY INSTRUCTIONS

314 - DRESSER


meridian.
furniture



+ Do Not Use
Power Tools



+ Suggested
Adults



NOTE: For questions and about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

Part 1 - **DRESSER**

Do not assemble if any of the following Hardware parts are missing:


Part E - **Tipping Restraint**

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

★ Remark: there is a tip restraint kit provided on the back of product. Please read the directions thoroughly and install Immediately when placed in home

STEP 1



+ Hardware Included

E: Tipping Restraint
(1 set)

