
Instruction Manual



HOS-PB-478
HOS-PB-479
HOS-PB-480
HOS-PB-481
HOS-PB-482 V1.0

Cabinet

EN

Thank you for purchase on our products. Please contact us if you have difficulty with assembly or need replacement parts. Our customer service is here to assist you.
Please attach your User Name or Order ID so that we can assist you better.

WARNING

Serious or fatal injury may occur from unexpected assembly or use.

1. During the assembly process, keep all parts away from babies or children.
2. Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
3. Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.
4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
5. Place the heaviest items on the lowest shelf.
6. Never allow children to climb or bang on drawers, doors or shelves.

DE


Vielen Dank für Ihren Kauf von uns Produkten. Bitte kontaktieren Sie uns, wenn Sie Probleme mit Montage haben oder Ersatzteile benötigen. Wir Kundenservice ist für Sie da.
Bitte geben Sie Ihren Benutzernamen oder Ihre Bestellnummer an, damit wir Sie besser unterstützen können.

WARNUNG





















Bei unerwarteter Montage oder Verwendung können schwere oder tödliche Verletzung auftreten.

1. Legen Sie in den Montageprozess alle Teile weg von Babys oder Kindern.
2. Stellen Sie sicher, dass der gebohrte Wandbereich frei von verborgenen Stromkabeln, Wasser- und Gasleitungen ist, wenn Sie dieses Produkt an der Wand befestigen.
3. Die Verwendung von Kippsicherungen kann die Gefahr eines Kippens nur verringern, jedoch nicht beseitigen.
4. Setzen Sie bitte keine schweren Gegenstände auf dieses Produkt, es sei denn, dass das Produkt speziell für die Unterbringung konzipiert wird.
5. Legen Sie bitte die schwersten Gegenstände auf das unterste Regal.
6. Erlauben Sie nie Kindern, auf Schubladen, Türen oder Regale zu klettern oder zu knallen.

Parts List(EN) / Teile Liste(DE)





Parts List(EN) / Teile Liste(DE)

A  M6×33mm 84+2PCS	**B**  Ø15×9mm 84+2PCS	**C**  Ø6×30mm 56+2PCS	**D**  2SETS
E  M4×12mm 2SETS	**F**  M3×12mm 8+1PCS	**G**  20+2PCS	**H**  M4×14mm 40+2PCS
I  10PCS	**J**  M3.5×12mm 62+2PCS	**K**  2SETS	**L**  M4×33mm 28+2PCS
M  M3×14mm 8+1PCS	**N**  2PCS	**O**  M4×13mm 3SETS	**P**  Ø20mm 12+1PCS
Q  L268mm 3PCS	**R**  M4×23mm 6SETS		
CL  L300mm 3PCS	**CR**  L300mm 3PCS	**DL**  L300mm 3PCS	**DR**  L300mm 3PCS


Assembly Steps(EN) / Montageschritte(DE)

STEP 1



	J x 6PCS
	CL x 1PC
	**CR** x 1PC


STEP 2




	A x 10PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 3




	J x 5PCS
	CL x 1PC
	**CR** x 1PC

Turn over part (4) to install the other side.

STEP 4




Turn over part (4) to install the other side.



	**A** x 10PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 5



Turn over part (8) to install the other side.

	**J** x 5PCS
	**CL** x 1PC
	**CR** x 1PC


STEP 6



	Mx 4PCS
	**K** x 1PC
	**D** x 1PC


Assembly Steps(EN) / Montageschritte(DE)


STEP 7



	L x 2PCS
	C x 2PCS

STEP 8






	B x 4PCS


Assembly Steps(EN) / Montageschritte(DE)

STEP 9




	B x 2PCS
	C x 2PCS

STEP 10




Assembly Steps(EN) / Montageschritte(DE)

STEP 11



	B x 6PCS
	C x 2PCS


STEP 12



	B x 4PCS
	C x 2PCS


Assembly Steps(EN) / Montageschritte(DE)

STEP 13




	**B** x 4PCS
	**C** x 2PCS

STEP 14




STEP 15




	**L** x 6PCS
	**C** x 6PCS


Assembly Steps(EN) / Montageschritte(DE)


STEP 16



 **A** x 8PCS


STEP 17




 **A** x 4PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 18




	B x 2PCS
	C x 2PCS




STEP 19




	B x 2PCS
	C x 2PCS



STEP 20




	**B** x 8PCS
	**C** x 6PCS





Assembly Steps(EN) / Montageschritte(DE)

STEP 21



STEP 22






	**A** x 4PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 23

Turn over part 20 to install the other side.



	A x 4PCS
	**D** x 1PC
	**M**x 2PCS


STEP 24




	**B** x 4PCS
	**C** x 4PCS

Assembly Steps(EN) / Montageschritte(DE)

STEP 25




STEP 26



	B x 4PCS
	C x 2PCS


Assembly Steps(EN) / Montageschritte(DE)

STEP 27




	A x 6PCS
	Mx 2PCS
	K x 1PC


STEP 28



	B x 6PCS
	C x 6PCS
	P x 6PCS


STEP 29






Assembly Steps(EN) / Montageschritte(DE)


STEP 30




	**C** x 6PCS
	**L** x 6PCS

STEP 31




	**A** x 8PCS

STEP 32




	**B** x 8PCS
	**C** x 8PCS



Assembly Steps(EN) / Montageschritte(DE)


STEP 33

Lock the long side of the "**E**" L-shaped metal plate to the ㉒ board with the "**E**" short screw.



	G x 20PCS
	J x 20PCS
	E x 2SETS


STEP 34




	H x 16PCS
	I x 8PCS
	R x 4SETS

x4

STEP 35






	H x 16PCS


Assembly Steps(EN) / Montageschritte(DE)

STEP 36




	K x 4PCS
	F x 4PCS

STEP 37



	D x 1PC
	F x 2PCS
	H x 4PCS
	I x 2PCS
	R x 1SET


STEP 38



	H x 4PCS


Assembly Steps(EN) / Montageschritte(DE)


STEP 39



A x 12PCS

STEP 40









B x 6PCS

Assembly Steps(EN) / Montageschritte(DE)


STEP 41





	B x 6PCS
	Q x 3PCS


STEP 42



	A x 6PCS


Assembly Steps(EN) / Montageschritte(DE)


STEP 43




	D x 1PC
	F x 2PCS
	N x 2PCS
	J x 4PCS
	R x 1SET

STEP 44








	B x 6PCS
	C x 4PCS
	P x 6PCS


STEP 45



	J x 4PCS


Assembly Steps(EN) / Montageschritte(DE)


STEP 46




	**L** x 12PCS


STEP 47




	**A** x 12PCS
	**B** x 12PCS
	**O** x 3SETS






STEP 48





x3



	**J** x 18PCS
	**DL** x 3PCS
	**DR** x 3PCS

STEP 49






Assembly Steps(EN) / Montageschritte(DE)

STEP 50

Drill 2 holes on the wall at the required position for anti-falling device installation.






E x 2PCS

STEP 51

Move the cabinet to the required position, use the "**L** " long screw to fix the cabinet to the wall.






L x 2PCS


The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.


Components Name



Obvious gaps between doors or Doors don't look closed



1 Turn "internal & external screw" to the right can make the door approach inside.
Please adjust the doors little by little.




※ If the 2 doors are overlap, please turn the "internal & external screw" to the left.

When door is crooked




Please take the following steps to adjust first.

1 Rotate the "front and rear screws" to the left




※ After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right Slightly.


2 Push the door to the cabinet




3 Rotate the "front and rear screws" to the right




When door is leaning




1 Turn "internal & external screw" to the left can make the top of the door tilted outward.







1 Turn "internal & external screw" to the left can make the bottom of the door tilted outward.




When the door is higher on top




1 Turn "up & down screw" to the left



2 Lower the door's height so that 2 doors are of the same height.



3 Turn "up & down screw" to the right



※ If the door is lower on bottom, please lift up the left door slightly on step 2

⚠ WARNING





Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **ALWAYS install Anti-tip device provided.**
- **NEVER put a TV on this product.**
- **NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.**
- **NEVER open more than one drawer at a time.**
- **Place heaviest items in the lowest drawers.**

This is a permanent label. Do not remove!

Made in China