


Pet gate




WARNING

- READ ALL INSTRUCTIONS BEFORE ASSEMBLY AND USE OF GATE.
- DO NOT CUT OFF THE BELT BEFORE INSTALLATION IS COMPLETED.
- KEEP INSTRUCTIONS FOR FUTURE USE.



WARNING

- ✘ Supervise your pet during playtime.
- ✘ Stop using if it becomes damaged or broken.
- ✘ For pet use only.
- ✘ Keep out of reach of children.
- ✘ This package contains small parts and sharp points in an unassembled state.
- ✘ Keep out of reach of children Adult assembly required.





As installation begins, you will notice a gap(it was not broken)



DO NOT CUT THE CABLE TIE
before the installation is completed.

PRODUCT & PARTS



HARDWARE			
E x4		F x4	
G x4		H x4	
I x1		J x8	

A Gate Door x1

B Extension 2.75" x1

C Encryption Rod x2

D Anti-stumble Pedal x1

E Tension Bolt x4

F Wall Cup x4

G Screw x4

H Dry Wall Anchor x 4

I Wrench x1

J M10 Nut X8




WARNING: This package contains small parts and sharp points in an unassembled state. Keep out of reach of children. Adult assembly required.


SPECIAL REMINDER BEFORE INSTALLATION

Installation method Optional for Pressure Mounted and Hardware Mounted,
Two installation methods, you can choose any one

METHOD A Pressure Mounted



METHOD B Hardware Mounted




Notice:


Screw in mounting cups when using gate on stairs.



Bottom of stairs





Top of stairs



METHOD A : PRESSURE MOUNTED INSTALLATION


STEP 1

Measure the width of the opening where you intend to install the gate. Please refer to the following diagrams to determine the correct installation configuration.




STEP 2

1. First, insert the extension bar into one side of the gate.
2. Install the encryption rod : Use one side of the gate as an example, insert the screw through the M10 nut(J), the encryption bar hole, another nut, and the large nut in sequence, then insert it into the side hole of the gate.
3. Install the anti-stumble pedal: Simply snap the anti-kick pedal onto the bottom of the gate.




Notice:

The bottom of the gate frame must be CLOSE to the floor, do not hang on the ground.




STEP 3



Rotate both of the bottom Tension Bolt as shown in the figure.
Note: Make sure the bottom of the gate frame remains completely flat on the floor.


Next, rotate both of the top Tension Bolt as shown in the figure.

STEP 4




Rotate 4 bolts

Tighten the bolts to ensure that the door bars are locked.



STEP 5



Cut off the belt and test the gate:


1. Push the gate to check stability.
2. Open and close the walk-through gate.

Opening Method:

Turn the upper iron piece up first and then lift the lower lock upwards.


METHODB: HARDWARE MOUNTED INSTALLATION

STEP 1




Pre-assemble the gate, and locate four points for hole drilling.
Hold the wall cup in position and mark the center with a pencil

STEP 2




According to your markings, drill holes in the corresponding locations, then insert the wall anchors and fix the wall cups with nails.

STEP 3



Cut the belt


Place the gate in the right position for fixed adjustment, and then cut the belt.



OPERATION FOR ADJUSTABLE SMALL GATE

The small pet door is 10.23 x 11.8 inches. You can adjust its size for your pet to go through appropriately.


1. Press both sides of the door inwards at the same time and then lift up (or down) to open and close the door.
2. The small gate has a total of 4 adjustment levels.



TROUBLE SHOOTING


A: The gate are too tight or not tight enough.

Solution: Please adjust the door clearance to 0.07in.




B: Gate is not properly aligned onto the door frame.

Solution: Adjust the gate by loosening all tension bolts and reposition gate. Make sure the gate is properly aligned onto the door frame/door opening. Then re-tighten tension bolts.



C: How to make sure the gate has been completely installed correctly?

Solution: Please refer to the following illustration, check through the top view and side view of the gate, and install it as required by the correct illustration.



D: If you need to remove the gate or reinstall it elsewhere in the future.

Solution: Before removing, tie the gate with cable zip tie to make sure the gate is locked. Next, loosen the 4 bolts in the direction shown in Trouble shooting and remove the gate.

Note: You must tie the gate with a tie before removing it. Otherwise, you may need the assistance of others to help you install it again.

INSTALLATION FOR EXTRA HIGH NETWORK

Extension Net Installation (Sold Separately) :

This net is an optional accessory and not included with the gate.


If purchased, follow the steps below.

STEP 1

According to the height requirements of use, you can install the main network accessories for additional height.

1. Insert the pins at the bottom of the main network into the top hole to place the main network temporarily;

2. Insert the long screws into the holes from top to bottom as shown, and use a screwdriver to tighten the screw to fix them.



INSTALLATION FOR EXTRA HIGH NETWORK

STEP 2

Installing the side nets on both sides of the main network according to the actual installation width requirements.

In order to facilitate your installation, please remove the heightening part first, and then assemble the widening part.

1. Adjust the required width on both sides and fix the upper and lower parts of the side nets to the main network by using snap iron sheet;
2. Use the attached short screws(N) and M5 nuts(P), install them in the order shown in the diagram, and tighten the screws to fix them with the help of wrench tools;

