








Assembly Instructions



Hardware

A  2 PCS	B  M6*15mm 24 PCS	C  M6*35mm 20 PCS	D  M6*40mm 8 PCS
E  M6*62mm 2 PCS	F  M8*50mm 4 PCS	H  28 PCS	


Part List

I  1 PC	J  1 PC	K  1 PC	L  1 PC
M  1 PC	N  1 PC	O  1 PC	P  2 PCS
Q  4 PCS	R  2 PCS	S  2 PCS	T  6 PCS
U  4 PCS	V 14 PCS	G  1 PC	


MC(K)

Assembly Instructions


Step1:




Step2:



Step3:




Step4:




Assembly Instructions


Step5:



Step6:




Step7:




Assembly Instructions


Step8:



Step9:



Step10:



WARRANTYINFORMATION

- Clean the surfaces preferable with a clean damp cloth, then dry with a clean towel.
- Do not use solvents or abrasive materialsto clean the unit. If you decide to use a cleaning agent, test first on an area hidden from view.
- Replacement parts might be available to you at no charge, with an original proof of purchase and where a defect has arisen, wholly or substantially, as a result of faulty manufacturing, parts or workmanship during the Warranty Period.
- The warranty does not ex tend to regular wear and tear, nor the manufacturer assumes liability for damages or consequences due to accidents. incorrect assembly, negligence, improper use, modifications, or not heeding the above warnings.

- Thank you so much for your support! We hope you enjoy your purchase. If there is any damage or missing accessories, please feel free to contact us for free replacement or refund. You can quickly find us through thise

  Service Email: **Service7770@outlook.Com**

  Service Line: **+1-888-292-2399**

  with your order numberwe will try our best to solve this problem for you !

Thank you !