


ASSEMBLY INSTRUCTIONS


SKU# 406/407/408 - 24", 30", 36", and 48"



+ Do Not Use Power Tools



+ Suggested Adults



NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:


- Part #① Wash Hand Table Top (1pc)
- Part #② Foot (4pcs)
- Part #③ Bottom Border (1pc)
- Part #④ Glass Shelf (1pc)

2 IMPORTANT ASSEMBLY INFORMATION

Do not tighten until all hardware is locked

+ Parts Included

① Wash Hand Table Top (1pc)




② Foot (4pcs)



③ Bottom Border (1pc)



④ Glass Shelf (1pc)



+ Hardware Included

A Bolt 5/16"*1-1/2"
(8pcs)



B 5/16" Spring Washer
(8pcs)





C Flat Washer D 5/16" Allen Key
(8pcs) (1pc)





ASSEMBLY INSTRUCTIONS **meridian.**
furniture

SKU# 406/407/408 - 24", 30", 36", and 48"


①



②



③



Rotate left and right
to adjust the level

NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.

www.MeridianFurnitureUSA.com | support@meridianfurnitureusa.com