



ASSEMBLY INSTRUCTION

WF309017/WF309018 TIPS



1. Please read the instructions fully before assembly. These instructions include important information which could ensure correct assembly. We have been working on providing high quality products for you. However, in the rare instance that your product is defective, missing parts or there are some issues, please don't hesitate to contact our customer service to submit parts requirements, assembly suggestion, or warranty claims, and we will give the best solution as soon as possible. If necessary, we need you to provide some more clear pictures of the issue.
2. Insert the screws in holes and tighten the screws, but not too tight, 70%~80% is ok, finally tighten all the screws. If some issues happened that some screws can not target to the hole or some parts are difficult to install, please adjust the tightness of the screws.
3. 2 people are recommended to finish.



Part List WF309017

3L Armrest - 3L (LH) X1	3R Armrest - 3R (RH) X1
---	---

Part List WF309018

1 Backrest X1	2 Side Rails X2	4 Side Rails X1	5 Side Rails X1	6 Slats X1
7 Slats X1	8 Slats X2	9 Connecting Rod X2	10 Leg X4	11 Wheel X4
12 Stop Block X2	P USB Power Transformer X1			

Hardware List WF309018

A Bolts(M8x25mm) X8	B Bolts(M8x40mm) X8	C Bolts(M6x25mm) X4	D Bolts(M6x35mm) X4	E Flat Washer X12
F Screw(3.0x20mm) X16	G Screw(4.0x30mm) X20	H Allen Key X1		

Step 1

- D




×4
- G



×4
- H




×1



Step 2



- A



×8
- H



×1



Step 3

- B




×4
- E




×4
- H




×1




Step 4




Step 5

F  x16




Step 6

C  x4

E  x4

H  x1



Step 7

- B




x4
- E



x4
- H



x1




Step 8

- G



x16



Step 9

