


ASSEMBLY INSTRUCTIONS

INSTRUCCIONES DE ENSAMBLE



Height: 32,08 in Alto: 81,5 cm
Width: 11,81 in Ancho: 30 cm
Depth: 9,96 in Fondo: 25,3 cm

IF ANY PARTS ARE BROKEN OR MISSING
PLEASE CONTACT US, OUR CUSTOMER
SERVICE TEAM WILL PROVIDE YOU HELP TO
RESOLVE ANY ISSUES IMMEDIATELY

**AUXILIARY
BATHROOM CABINET**
Mueble Auxiliar de baño



IMPORTANT RECOMMENDATIONS

Do not paint the cabinet.

The cabinet **MUST** be used exclusively indoors, do not expose to direct sun.

Clean metallic hardware with a dry cloth.

Do **NOT** overload the cabinet (see suggested loads).

Do not hit or hammer the cabinet (just when indicated).

Clean with a slightly damp cloth, use gentle soaps.

Do not drag, lift and move between two people.

Avoid direct contact with water, fire or exposure to heat sources.

RECOMENDACIONES IMPORTANTES

No pintar el mueble.

El mueble debe ser usado únicamente en interiores, no exponer al sol directo.

Limpiar los herrajes metálicos con un paño seco.

NO sobrecargar el mueble (ver las cargas sugeridas).

No golpear ni martillar el mueble (solo cuando se indique).

Limpiar con un paño ligeramente húmedo, usar jabones suaves.

No arrastre el mueble, levántelo entre dos personas.

Evite el contacto directo con el agua, el fuego o la exposición a fuentes de calor.



WARNING

Never allow children to climb or manipulate the cabinet, furniture tip over can cause serious injuries or death.



ADVERTENCIA

Nunca permita que los niños escalen o manipulen el mueble, la caída de este puede provocar lesiones graves o la muerte.


INDEX

Assembly Hardware	4
Assembly Parts	5
Suggested Loads	6
Assembly Recommendations	6
Assembly Steps	7-15
Warranty	16

ÍNDICE


Herrajes para Armado	4
Piezas de Armado	5
Cargas Sugeridas	6
Recomendaciones de Ensamble	6
Pasos de Armado	7-15
Garantía	16

REQUIRED TOOLS*



*Not included, and not shown actual size.

HERRAMIENTAS NECESARIAS*



*No incluidas y no se muestran en tamaño real.

ASSEMBLY HARDWARE

Please check that the hardware content is correct. If any item is missing, please call to our customer service line.

HERRAJES PARA ARMADO

Compruebe que el contenido de los herrajes sea el correcto. En caso de que falte alguna pieza, por favor llame a nuestra línea de atención al cliente.



x16

Minifix Cams
Minifix




x16

Spreading Bolt
Perno Minifix




x23

Wood Dowel
Tarugo



x1

Glue
Pegante



x1

Handle
Manija Acero



x2

Drywall Screw
Tornillo de Ensamble



x8

Nail
Puntilla




x14

Flat Head Screw
Tornillo Lámina



x18

Cover Caps
Tapa Adhesiva
Minifix



x2

Inset Hinge
Bisagra Parche



x2


Drywall Screw +
Wall Anchor
Chazo Mariposa
+ Tornillo Ensamble

Hardware items are NOT shown actual size.

Los herrajes no se muestran en el tamaño real.

ASSEMBLY PARTS

PIEZAS DE ARMADO



A - x1

B - x1

C - x1

D - x1

E - x1

F - x1

G - x1


H - x1

I - x1

J - x1

K - x1

MAX SUGGESTED LOADS




ASSEMBLY RECOMMENDATIONS

Two people are recommended to assemble the product.

Assemble the cabinet on a flat, smooth surface, preferably on a carpeted floor or the carton box of the product.

Carefully read the assembly instructions and identify every wood and hardware part before start assembling the cabinet.

CARGAS MÁXIMAS SUGERIDAS




RECOMENDACIONES DE ENSAMBLE


Ensamble el mueble entre dos personas.

Ensamble el mueble sobre una superficie plana y lisa, preferiblemente sobre un tapete o el cartón de la caja


Lea cuidadosamente las instrucciones e identifique todas las piezas y herrajes antes de empezar a armar el mueble.




3




4




5




6




7




8




9




10



11




12





Gently hit the pieces
with a rubber hammer
to adjust the joint.

Golpee suavemente la
pieza con un martillo
de goma para ajustar
el ensamble.





13





Turn minifix cams to the right to tighten.
Gire las cajas minifix hacia la derecha para apretar las piezas.

14






15



Turn minifix cams to the right to tighten.

Gire las cajas minifix hacia la derecha para apretar las piezas.

16




After you finish the adjustment of the cams, cover them with the cover caps.


Después de ajustar todas las cajas minifix, cúbralas con las tapas adhesivas.

17


Door Installation Instalación de las Puertas





Height adjustment
Ajuste de altura




Depth adjustment
Ajuste de profundidad



Side adjustment
Ajuste lateral





x4



Tools not included
Herramienta No incluida
5/16" / Drill Bit

Hinge adjustment
Ajuste de las bisagras

Wall Installation Instalación a la pared



A

After you finish assembling the cabinet, take off the adhesive letters.

Al terminar de armar, despegue las letras adhesivas.

WARRANTY POLICY

PÓLIZA DE GARANTÍA

We have a 3 year warranty coverage in wooden parts and 1 year warranty coverage in hardware pieces since its manufacturing date, which you can see in the lot number printed on the product box and the assembly instructions leaflet.

Warranty covers materials and workmanship imperfections which impair the assembly or correct functioning of the cabinet.

This warranty is not valid if the defects or imperfections are caused by the incorrect following of the assembly instructions, warnings and recommendations, misuse, intentional damage, fire or flood, or after modifications or any kind of alteration, or repaired by someone not authorized by us, when it's been assembled 3 months after the date of purchase. These defects MUST be reported before the warranty coverage period ends. Once the product has been assembled, the company will not be responsible for defective and/or damaged parts.

This warranty is ONLY valid for the ORIGINAL PURCHASER, it doesn't apply if the product has been resold, rented, etc.

We will take no liability for incidental or consequential damages caused to or by the product (This may not apply in your state).

To make this warranty valid you must write to our customer service email describing the product defect, lot number and submitting your sales receipt or proof of purchase, or contact us at our customer service line. Replaced parts will be under the product's original warranty coverage period. Damaged parts will become property of the company.

There are no other warranties applicable to this product.

**IF ANY PARTS ARE BROKEN OR MISSING
PLEASE CONTACT US FIRST
OUR CUSTOMER SERVICE
TEAM WILL PROVIDE YOU HELP TO RESOLVE
ANY ISSUES IMMEDIATELY**