

CARE AND MAINTENANCE










Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.


NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening.

PART LIST AND HARDWARE LIST

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TABLE TOP		1X
B	LEFT LEGS (L&R)		2X
C	RIGHT LEGS (L&R)		2X
D	CENTER STRETCHER		1X
E	SIDE STRETCHER		1X
F	SIDE PANEL (L & R)		2X
G	BACK PANEL		1X
H	SHELF		3X
H1	LONG BOLT	7.8*60 mm 	8X

Product Dimensions: 48"W x 36"D x 36"H



Weight capacity: 25lbs
WARNING: DO NOT STAND ON TABLE
WARNING: DO NOT OVER TORQUE BOLTS











PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 20 minutes.

Tools Required for Assembly (included): Allen Key


PIECE	DESCRIPTION	PICTURE	QUANTITY
H2	SHORT BOLT	6.3*40 mm 	6X
H3	SPRING WASHER	6.3*40 mm 	14X
H4	SMALL WASHER	7.8*16 mm 	2X
H5	BIG WASHER	7.8*19 mm 	12X
H6	SCREW	5*50 mm 	2X
H7	ALLEN KEY		1X
H8	WOODEN PLUG	Ø18 mm 	1X
H9	CAM SCREW	Ø6*40 mm 	6X
H10	CAM LOCK	Ø15*12.5 mm 	6X
H11	WOODEN PEGS	Ø10*30 mm 	4X




STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7



STEP 8



STEP 9



STEP 10

CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.














NOTICE

* Please make sure that you have all parts indicated before you begin assembly of this item


* This item should be assembled on a soft surface to prevent scratching the finish during assembly

* This item may require periodic tightening.

PART LIST AND HARDWARE LIST

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	BACK CHAIR		1X
B	SEAT FRAME		1X
C	FRONT LEGS (R & L)		2X
D	FRONT STRETCHER		1X
E	SIDE STRETCHER (R & L)		2X
H1	LONG BOLT	6.3*75 mm 	4X
H2	SHORT BOLT	6.3*40 mm 	2X
H3	NUT		4X
H4	SPRING WASHER		10X
H5	WASHER		10X
H6	SCREW	4*38 mm 	6X
H7	ALLEN KEY		1X
H8	WRENCH		1X

Product Dimensions: 17"W x 19-1/2"D x 39"H



Weight capacity: 25lbs
WARNING: DO NOT STAND ON CHAIR
WARNING: DO NOT OVER TORQUE BOLTS


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.


If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key



STEP 1



STEP 2