







Assembly Instruction - Folding Stackable Bookcase

NO	DESCRIPTION	Q'TY
RF50044	 Brackets	2
RF10004	 Screws F6 x 5/8"	12
RF10002	 Screws F6 x 1 1/4"	2
RF50003	 L-Bracket	2
RF44080	 Caps	6



Single Unit

Step 1.

Open side panels (Diag. 1.) and while they are opened lower each shelf as per Diag. 2. Make sure each shelf is resting on each metal clip.

Step 2.

Cover the screw holes with Cap (RF44080).




Diagram 1.






Diagram 2.


Stacking Two Units



Wall



Used 1-2 L-brackets (RF50003) and screws F6 x 5/8" (RF10004) to attach two side panels to the studs in the wall, using screws F6 x 1 1/4" (RF10002) as per Diag.



When stacking, use brackets included, and attach as per diagram.