















PARTS LIST

NO	DESCRIPTION		QTY
A	Left Chair Arm		1
B	Right Chair Arm		1
C	Chair Back		1
D	Chair Seat		1
E	Chair Legs		4
F	Screw	$\Phi 5/16'' * 3-7/8'' L$ 	2
G	Flat Washer	$\Phi 5/16'' * 22mm$ 	4
H	Lock Washer	$\Phi 5/16''$ 	4
I	Allen Wrench	$\Phi 5mm$ 	1
J	Screw	$\Phi 1/4'' * 1'' L$ 	16
K	Flat Washer	$\Phi 1/4'' * 13mm$ 	16
L	Lock Washer	$\Phi 1/4''$ 	16
M	Allen Wrench	$\Phi 4mm$ 	1


STEP1

Fasten chair arms from the bottom up.




STEP2

Insert and push backwards.



STEP3

Turn the chair upside down and install the screws (F)



STEP4

Install four chair legs

