




ASSEMBLY INSTRUCTION




PART LIST



HARDWARE LIST

Label	Picture	Description	Qty	Label	Picture	Description	Qty
1		Bolt M8x20	14	3		Nut M8	12
2		Bolt M8x40	12	4		Foam Pad	1
				8		Foam Pad	2

TOOL list


Label	Picture	Description	Qty
5		Allen key M5 M6	2
6		Spanner M12	1
7		Spanner M13	1

1

8PCS




Bolt M8x20

Step 1

5



Allen key M6


Step 2

5



Allen key M6

Step 3



J

2PCS



Connection Plate

1

4PCS




Bolt M8x20

5



Allen key M6


Step 4



I	1PCS	1	2PCS
			
	Footboard Plate		Bolt M8x20


5	
	Allen key M6

Step 5




5	
	Allen key M5

Step 6




2	8PCS	3	8PCS
	Bolt M8x40		Nut M8
5		6	
Allen key M6		Spanner M12	

Step 7



H	2PCS
	
Mattress stoper	

Step 8




K


2PCS


Pneumatic
support rod

Step 9



K




M


1PCS


Puller

Step 10






M






2	4PCS	3	4PCS
	Bolt M8x40		Nut M8
5		6	
Allen key M6		Spanner M12	

Step 11



4	1PCS
	Foam Pad



Step 12



8 2PCS

Foam Pad



Step 13




L 1PCS

Bottom fabric


Step 14



Step 15



Step 16



Attention: Please remove mattress from the bed should you wish to clean the floor under the bed. Dragging the bed around with mattress might compromise the bed construction , stability or cause permanent damage.

Hints and Tips

- Failure to do so may result in injury.
- To operate the ottoman, always use two hands at arm's length to push down on the bed frame end, in between the 2 rows of slats (as shown below) to close the bed frame.
- To open, lift up using the nylon strap on the bed end. You must always ensure the mattress is on the bed frame before lifting to open and close the bed frame.
- The weight of the mattress loaded on the frame helps to close the bed frame easier and with less effort, also keep the frame inclosed position until it is pulled upwards by user.

Please ensure the pistons are fitted to the bedframe.

-Please place the mattress on top of the bedframe.


-Standing at the foot of the frame (looking at the headboard), open the base and press quite forcefully down on the mattress. Please do not attempt to do this without the mattress being in place.

-Please do not pull on the strap handles. Please note, as the pistons are full of gas, you will need to press heavily to release the compressed gas.

-Once done, the pistons should start operating as normal.

The reason why the support legs break in the follow circumstances ,please be carefully :

1. After used the bed for more than 4 monthes the customer need to retight all the screws especially for the support legs ,Since it is KD it will be loosed
2. The mattress Need over 20cm
3. Please dont push the bed against the wall ,it need lift up and move to the wall , bez once you push the bed to the wall ,the legs will become lean positon which it is not stright so it will be break with lean position



Always Ensure Mattress Is On The Bed Frame While Lifting.

