


Installation method

※Please confirm the bearing strength of floor and ceiling

- Adjust the rod height to applicable place height plus 2cm



- Confirm whether the rod is straight or not
- Confirm whether the rod is stable or not
- Confirm whether the stand is fixed well or not