



REMOVES HARMFUL CONTAMINANTS
REMOVES SELECTED MICROBIOLOGICAL PATHOGENS
CERAMIC AND 5-STAGE EFFECTIVE FILTRATION PROCESS
PLACE ANYWHERE IN YOUR HOME, OFFICE OR WORKPLACE
A TRADITIONAL WAY TO PRODUCE CRYSTAL CLEAR MINERAL WATER
NO POWER NEEDED - SIMPLY FILL WITH FRESH WATER FROM TOP SECTION
EASY TO ASSEMBLE AND USE - SIMPLY PUSH LEVER DOWN TO DISPENSE WATER

For more information please contact:

AFRICA: Tel:+27 11 784-4444 | Fax: 011 784-3746 | Email: info@littlexury.co.za | www.littlexury.co.za
Address: 94 11th Street, Parkmore, Sandton, 2146, South Africa
USA: Tel: +1 855 255-5544 | Fax: 214 550-4300 | Email: info@littlexury.com | www.littlexury.com
Address: 4923 Cape Coral Drive, Dallas, TX 75287, United States

This product is subject to patent, copyright, utility design right and utility model and design right protection internationally. Water-Stream™ has every legal effort to protect its product and will vigorously pursue legal resource with any company which may infringe on their intellectual property rights. Specifications may change without notice.



CRYSTAL CLEAR™ DESKTOP DISPENSER INSTRUCTION MANUAL



AFRICA: Tel:+27 11 784-4444 | Fax: 011 784-3746 | Email: info@littlexury.co.za | www.littlexury.co.za
Address: 94 11th Street, Parkmore, Sandton, 2146, South Africa
USA: Tel: +1 855 255-5544 | Fax: 214 550-4300 | Email: info@littlexury.com | www.littlexury.com
Address: 4923 Cape Coral Drive, Dallas, TX 75287, United States

CRYSTAL CLEAR™ DESKTOP DISPENSER



1 Remove the Crystal Clear™ 5-Stage Filter Cartridge and rinse it under running water for about 30-60 seconds. It is recommended that the Crystal Clear™ Ceramic Filter is rinsed under running water before use.



2 Place a silicon o-ring in line with the hole at the bottom of the container/tank. Place the tap through the hole and insert another silicon o-ring around the tap on the inside of the container/tank.




3 Place the bottom tank onto the white base and insert the Crystal Clear™ 5-Stage Filter Cartridge on the top section.



4 Once filters have been placed and are secure, fill the top part of the container with regular tap water and it will flow down into the bottom section, through the filters.

CRYSTAL CLEAR™ DESKTOP DISPENSER



Crystal Clear™ Ceramic Filter

Filters out rust, sediment and harmful bacteria. Removes typhoid, cholera & E-coli. Simply rinse when dirt builds up. Replace once every 3 months.



Crystal Clear™ 5-Stage Filter Cartridge

Removes chlorine, heavy metals (lead, mercury, aluminum). 5-stages of filtration ensures all unwanted bacteria is removed. Improves odor and taste of water. Replace once every 3 months.

