


















Suggestion

- It is recommended to install it near a power source, as later steps will require the power to be turned on.
- This product requires installation by at least two people.




















ASSEMBLY INSTRUCTION























ASSEMBLY INSTRUCTION

①  1PC	②  1PC	③  2PCS	④  2PCS
⑤  2PCS	⑥  1PC	⑦  1PC	⑧  2PCS
⑨  1PC	⑩  1PC	⑪  2PCS	⑫  2PCS
⑬  1PC	⑭  1PC	⑮  1PC	⑯  1PC
⑰  1PC	⑱  1PC	⑲  1PC	⑳  1PC




ASSEMBLY INSTRUCTION

②1 1PC 	②2 1PC 	②3 1PC 	②4 1PC 
②5 1PC 	②6 1PC 	②7 1PC 	②8 1PC 
②9 1PC 	③0 1PC 	③1 1PC 	③2 1PC 
③3 1PC 	③4 1PC 	③5 1PC 	③6 1PC 
③7 1PC 	③8 1PC 	③9 1PC 	④0 1PC 





ASSEMBLY INSTRUCTION

④1	1PC	④2	1PC	④3	2PCS	④4	1PC
							
④5	2PCS	④6	2PCS	④7	2PCS	④8	3PCS
							
④9	2PCS	⑤0	1PC	⑤1	1PC	⑤2	1PC
							
⑤3	1PC	⑤4	2PCS	⑤5	1PC	⑤6	1PC
							
⑤7	1PC	⑤8	1PC	⑤9	1PC	⑥0	1PC
							






ASSEMBLY INSTRUCTION

⑥1	1PC	⑥2	2PCS	⑥3	1PC	⑥4	2PCS
							
⑥5	2PCS	⑥6	1PC	⑥7	2PCS	⑥8	1PC
							

"A" Hardware installation example


I 	II 
III 	IV 

ASSEMBLY INSTRUCTION


















A 12PCS  M6*30	B 10PCS  M6*10	C 1PC  M4	D 4PCS  M6*10
E 6PCS  14"	F 2PCS  M8	G 1PC 	H 4PCS 
I 1PC 	J  4PCS  8PCS	K 151PCS  M6*40	L 151PCS  Ø15*9.5
M 88PCS  Ø3.5*14	N 12PCS  Ø3.5*40	O 12PCS  Ø5*15	P 8PCS 
Q 4sets  96#  M4*20	R 16PCS 	S 2PCS  Ø50	T 1PC 
U 4PCS  Ø8*40	V 151PCS 	W 16PCS  M6*16	X 2PCS  Ø3.5*25
Y 2PCS  M8*16	 M4  M5 		

Step 1




K 125PCS



M6*40





Step 2




K 26PCS
M6*40

Step 3



L 3PC
Ø15*9.5

Step 4




L 2PCS
Ø15*9.5

ASSEMBLY INSTRUCTION

Step 5

L 1PC


Ø15*9.5



Step 6

L 5PCS


Ø15*9.5



Step 7


L 2PCS

Ø15*9.5



L 10PCS


Ø15*9.5



ASSEMBLY INSTRUCTION

Step 9


L 6PCS
Ø15*9.5



Step 10


G 1PC

M 2PCS
Ø3.5*14




Step 11

L 11PCS
Ø15*9.5




Step 12



M 4PCS
Ø3.5*14





Make sure the accessory nuts face outward during installation.





Step 13





Step 14




Step 15



Step 16




Step 17



Step 18


M 8PCS
Ø3.5*14



Please press here
to open the door
panel.


Step 19

L 3PCS
Ø15*9.5




Step 20

L 3PCS
Ø15*9.5




Step 21

L 6PCS
Ø15*9.5




Step 22

L 4PCS
Ø15*9.5




Step 23

L 4PCS
Ø15*9.5




Step 24


L 7PCS
Ø15*9.5





Step 25



Ex6



Step 26




ASSEMBLY INSTRUCTION

Step 27

L 5PCS


 Ø15*9.5



Step 28

L 5PCS

 Ø15*9.5




Step 29

L 12PCS

 Ø15*9.5


Requires two or
 more people to
 install.



Step 30

L 18PCS


 Ø15*9.5




Step 31

M 4PCS

 Ø3.5*14




Make sure the accessory
nuts face outward during
installation.




Step 32

A 4PCS






Step 33

R 10PCS






Step 34




E2	4PCS	L	8PCS
	14"		Ø15*9.5
Q	2sets	M	8PCS
96#	M4*18		Ø3.5*14
N	8PCS		Ø3.5*40

Step 35



E2	2PCS	L	4PCS
	14"		Ø15*9.5
Q	1set	M	4PCS
96#	M4*18		Ø3.5*14
N	4PCS		Ø3.5*40


Step 36




Step 37

0 8PCS

 Ø5*15





Step 38



Step 39


M	8PCS
	
	Ø3.5*14
P	4PCS
	



Step 40

M 16PCS


Ø3.5*14



Step 41


L 6PCS

Ø15*9.5



Step 42


Attention, please! Lift accessory 1 and accessory 2 up by hand to the same level to facilitate the installation of accessory 5 in step 43.



Step 43

B	4PCS
	
	M6*10
C	1PC
	
	M4


Note that the "gourd-shaped hole" here on the front crossbeam is close to the left cabinet




Step 44

Attention, please! Install accessory 5, which is the crossbeam, and press the legs on both sides to the lowest position.

⚠ If it is not pushed all the way to the bottom, it may cause the product to have uneven legs, which can result in an uneven tabletop.




Step 45




Step 46


B 2PCS
M6*10



Step 47




Step 48



Note: If the transmission rod doesn't fit smoothly into the hole of rod coupler, fine-tune it with the wrench.

Step 49




Step1: Connect the controller of the lifting frame, namely accessory 6, to the plugs of the other two accessories 10 and 13, and then turn on the power.


Step2: Press the downward button on the controller for 5 seconds- the hand controller will display "RST". Release the button, then hold down the downward button again until the digital tube shows a number.

Step3: Press and hold the "Rise" button, raise the lifting frame to a certain height, then turn off the power and proceed to the next installation step.

Step 50




Step 51



B 4PCS
M6*10


Step 52

A 4PCS
M6*30




Step 53

D 4PCS
M6*10




Step 54

The tabletop is too heavy. It is recommended to move the two boards here to the tabletop and then join them together.



U 4PCS
Ø8*40


Step 55




W 16PCS
M6*16

Attention, please! At this step, screw W cannot be locked yet. All 16 screws need to be locked before tightening screw W uniformly.


Step 56



S	1PC	M	2PCS
			
Ø50		Ø3.5*14	
		X	2PCS
			
		Ø3.5*25	




Step 57



L	2PCS
	
Ø15*9.5	

Step 58




I	8PCS
---	------



Ø15*9.5

Step 59




L	4PCS
---	------




Ø15*9.5

Step 60




M	2PCS
	
Ø3.5*14	
S	1PC
	
Ø50	
T	1PC
	

Step 61



L	12PCS
	
Ø15*9.5	


Step 62



To prevent the power adapter from being damaged and from loosening, please use a pull strap to secure the cable.

H	4PCS
M	2PCS
Ø3.5*14	

Step 63



Y	2PCS
M8*16	

OK

Instruction Manual for JCB35M51C Controller (Version 1.0-English)


System Function Description:

1. Lifting and Lowering Function of the Height-Adjustable Desk:

Hold down the upward button, and the column will rise; hold down the downward button, and the column will lower. Release the button, and the movement will stop.

2. Memory Position Function:

Long press the "①/②" button for 3 seconds until the digital tube display flashes. After the number flashes 3 times and stops, the current height will be successfully stored in the corresponding memory position. Short press the "①/②" button and release it, and the tabletop will automatically move to the height of the memory position. During operation, pressing any button can stop the movement.



3. Reset Function:

(1) Function Description:

The system needs to be reset under specific circumstances.

These circumstances include:

- ① When used for the first time, the system will enter the reset state after being powered on.
- ② Active reset will put the system into the reset state.
- ③ A system abnormality will cause the system to enter the reset state.

(2) Operation Method:

Bottom Reset: Hold down the downward button until it reaches the bottom. Then release the button, and press the downward button again for 5 seconds—the hand controller will display "RST". Release the button, then hold down the downward button again until the digital tube shows a number.

