


ASSEMBLY INSTRUCTIONS

GZDW-V1

FTLFST-6023




SIDE TABLE

Notice:

1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.


FTLFST-6023

①



1PCS

②



1PCS

③




1PCS

④




1PCS

⑤



1PCS

⑥



1PCS

⑦




1PCS

⑧



1PCS

⑨




1PCS

⑩




1PCS

⑪




1PCS

⑫



2PCS

⑬



1PCS

⑭







1PCS

⑮




2PCS

FTLFST-6023

A  M6 3SETS	B  M6*35 1PCS	C  M6*25 12PCS	D  M6*12 8PCS
E  M7*38 14PCS	F  M3.5*14 8PCS	G  7PCS	H  7PCS
I  2PCS	J  M4*14 8PCS	DL CL DR CR 10" 1SETS	L L1 L2  M4*18 1PCS
M  1PCS	N  8*30 2PCS	O  M7*48 4PCS	

FTLFST-6023




FTLFST-6023

STEP 1

13  1PCS

15  2PCS

A  3SETS




STEP 2

13  1PCS

14  1PCS


B  1PCS



FTLFST-6023


STEP 3

1		1PCS
C		4PCS




STEP 4

D		8PCS
I		2PCS




FTLFST-6023

STEP 5



3		1PCS
4		1PCS
F		4PCS
CL		1PCS
CR		1PCS


STEP 6



12		2PCS
15		2PCS
E		8PCS


FTLFST-6023

STEP 7



3		1PCS
4		1PCS
5		1PCS
C		4PCS
O		4PCS


STEP 8



2		1PCS
C		4PCS
G		3PCS
H		3PCS


FTLFST-6023

STEP 9



J		4PCS
M		1PCS


STEP 10



J		4PCS
---	---	------

FTLFST-6023


STEP 1 1



7		1PCS
8		1PCS
10		1PCS
11		1PCS
G		4PCS
H		4PCS
N		2PCS

STEP 1 2


9		1PCS
---	--	------



FTLFST-6023


STEP 13

6		1PCS
E		6PCS




STEP 14

L		1PCS
---	---	------




FTLFST-6023

STEP 15



F		4PCS
DL		1PCS
DR		1PCS

STEP 16



FTLFST-6023

