




# Assembly Installation



110~240V

50Hz/60Hz

MAX:E27\*1PCS



110~240V  
50HZ/60HZ

- ☆ Only the technical personnel can be allow to fix and maintain
- ☆ You must turn off the power before to fix
- ☆ If the glass is breakdown you must change it immediately
- ☆ There must keep some space for radiation

