

OVENTE®

450-WATTS PROFESSIONAL BLENDER

BHL1602 SERIES



Before use, please read this manual thoroughly and save for future reference.

ovente.com

450-WATTS PROFESSIONAL BLENDER

BHL1602 SERIES



450-WATTS PROFESSIONAL BLENDER

BHL1602 SERIES

TABLE OF CONTENTS

IMPORTANT SAFETY	4
PARTS AND FEATURES	5
USING THE BLENDER	7
HOW TO STORE THE BLENDER	8
CARE AND MAINTENANCE	8
ELECTRICAL REQUIREMENTS	9



IMPORTANT SAFEGUARDS

Before use, please read this manual thoroughly and save for future reference.

- ❗ Please keep the instruction manual, guarantee certificate, sales receipt and if possible, the carton with the inner packaging.
- ❗ Before plugging in the appliance, check that the socket and power matched those of the appliance.
- ❗ Only connect the unit to an AC power supply. The voltage listed on the rating plate must coincide with the voltage of your power supply.
- ❗ Extreme caution must be used when moving an appliance containing hot liquids.
- ❗ Always remove the plug from the socket when the Professional Blender is not in use. Allow it to cool down before putting on or taking the parts off. Do not touch or insert plug with wet hands to avoid electric shock.
- ❗ Prevent the product from exposing to excessive dirt and humidity.
- ❗ Do not attempt to repair or modify the Professional Blender, only authorized and qualified Personnel may repair this blender.
- ❗ Never dip machine into any liquid. Do not use the appliance with wet hands; if the appliance is humid or wet, unplug it immediately.
- ❗ This appliance should not be used by people (including children) with reduced physical, sensory or mental capabilities. It is not intended for people with lack of experience and knowledge unless they are supervised by the person who is responsible for their safety.
- ❗ Keep children away from the appliance. Pay particular attention when children are in the vicinity.
- ❗ Do not connect incompatible products or items not included in the package.
- ❗ Keep your fingers away from moving parts and fitted tools. Never put your fingers in hinge mechanism.
- ❗ Do not interfere with the machine's safety switches.
- ❗ Place the machine on a smooth, flat and stable working surface.
- ❗ Wait until moving parts stop running before you remove the lid of machine.
- ❗ Do not plug or operate the Professional Blender with a damaged cord. If the cord is damaged or if the Blender has been malfunctioned in any manner, contact your service provider immediately.
- ❗ When disconnecting the power cord, grasp and pull the plug carefully.
- ❗ Prevent squeezing the cord during installation or cleaning as it may damage the cord.
- ❗ Keep the cables away from appliances which generates excessive heat.
- ❗ Avoid danger of tripping, do not allow the electric cable to hang down.
- ❗ Keep the Professional Blender far away from hot appliance, gas or electric hot stoves.
- ❗ The Professional Blender is for household use only.

⚠ Operate the blender in less than 2 minutes and let it rest for at least 1 minute before proceeding to the second operation.

⚠ NOTE: Do not use the blender for more than 2 operations. Allow blender to cool off for 30 minutes before using it again

PARTS & FEATURES



- 1 Removable Filler Caps with Measurements - Reduces backsplash when adding veggies, ice, and/or other ingredients in your blender.
- 2 1.5 Liter (50oz) Capacity - BPA-Free with safety switch lock.
- 3 Comfortable Soft-Touch Handle - Easy to grip for graceful pouring.
- 4 Stainless Steel Blades - Durable and Reliable crushing blades handle the toughest ingredients with ease
- 5 450-Watt Power - Quickly and seamlessly blends ingredients together to make delicious and healthy smoothies, purees, creamy soups, marinades, sauces, juices and much more.
- 6 2 Blending Speed with Pulse Function - Blend to your perfect texture and consistency.
- 7 Anti-Skid Feet - For extra safety and stability.

450-WATTS PROFESSIONAL BLENDER

BHL1602 SERIES



SMOOTHIES

Get creative with different kinds of fruit, juices, and milk. It's more fun with almond butter, chia seeds, or cocoa!



PUDDING

You can't go wrong with a delicious homemade pudding.



DRESSING

Making your own dressing gets easier and tastier than store-bought with a blender.



SORBET

No ice cream maker required if you have a blender to make a sorbet. Achieve a cold, sweet treat with a frozen fruit, sweetener and a blender.



USING THE BLENDER

! NOTE: Before connecting to the power outlet, recheck if the supply type and the mains voltage are matched with the details given on the rating label of the appliance.

1 Step 1
Fit the blender jar onto the motor unit.

2 Step 2
Following the indication marks on the base, turn the blender jar counterclockwise to lock in the blender jar.

Wash the ingredients or cut fruits/vegetables into small pieces.

Place the ingredients into the blender jar and add desired liquid mixture into the jar. Pay attention that food should not exceed the jar's highest line.

3 Step 3
Attach the lid onto the blender jar.

Turn the lid counterclockwise to lock in the blender jar.



4 Step 4
Attach the filler cap into the lid

Plug the appliance and turn the speed button to 1, 2 or depending on your food request

Operate the blender in less than 2 minutes and let it rest for at least 1 minute before proceeding to the second operation.

NOTE: Do not use the blender for more than 2 operations. Allow blender to cool off for 30 minutes before using it again.

- Never open the lid when the blade is still rotating. For extra caution, unplug the appliance before removing the lid.
- To add liquid ingredients during the process, remove the filler cap and pour liquid through the opening
- If not satisfied with the result, switch the blender off, remove the lid and stir the ingredients with a spatula(not included).



HOW TO STORE THE PROFESSIONAL BLENDER

- ★ Step 1
Place the blender jar upside down and insert into the motor unit.
- ★ Step 2
Attach the lid onto the blender jar.
- ★ Step 3
Insert the filler cap into the lid.



CARE AND MAINTENANCE

- Prevent the product from exposing to excessive dirt and humidity.
- Do not immerse the housing with motor in any liquid.
- Remove the power cord from the socket before cleaning the Professional Blender.
- Do not use any abrasive detergents in cleaning the machine
- Only use soft, damp cloth in cleaning the outside of the housing
- Food residue can be cleaned in soapy water
- Allow parts to dry thoroughly before reassembling the blender
- When disconnecting the power cord, grasp and pull the plug carefully.
- Operate the blender in less than 2 minutes and let it rest for at least 1 minute before proceeding to the second operation.
- NOTE: Do not use the blender for more than 2 operations. Allow blender to cool off for 30 minutes before using it again.



ELECTRICAL REQUIREMENTS

Voltage: 120V

Power: 1500W

Hertz: 60Hz

450-WATTS PROFESSIONAL BLENDER

BHL1602 SERIES





OVENTE WARRANTY

Register your product within **30** days of purchase to activate its one-year limited manufacturer's warrant at ovente.com/register

NOTE: WARRANTY IS ONLY VALID IF YOU REGISTERED WITHIN 30 DAYS AFTER PURCHASE.

LIMITED ONE (1) YEAR WARRANTY:

Your product has a one (1) year warranty period from the date of purchase from an authorized retailer. In the event that the product is defective, feel free to contact us to arrange for a replacement. This warranty only covers defects in workmanship and materials. The warranty does not include damage due to abuse or misuse, any commercial use or accidents.

LIMITATIONS

The warranty stated above is the only warranty applicable to this product. Other expressed or implied warranties are hereby disclaimed. No verbal or written information given by the Manufacturer, its agents or employees shall create a guarantee or in any way increase the scope and duration of this warranty. Repair or replacement as provided under this warranty is the exclusive remedy of the consumer. The manufacturer shall not be liable for incidental or consequential damages resulting from the use of this product. Any implied warranty of merchantability or fitness for a particular purpose on this product is limited to the applicable warranty period set forth above except to the extent prohibited by law. Consumer rights may vary from state to state.

Customer Support: ovente.com/support

Visit us at ovente.com

OVENTE®

Defining Housewares