

Thank you for your purchase! It is our desire to make your entire experience from purchase to installation as easy as possible. We ask that you read each step of this installation manual thoroughly to ensure proper installation of your new Tear Drop Glass Table. Our installation techniques are very important. Installing your Table in any manner other than the steps outlined in this manual may lead to structural failure of your Table.





CAUTION

It is your responsibility to see that your Tear Drop Glass Table is properly assembled, installed, and cared for. Failure to follow instructions in this manual could result in serious injury. Use this product with Glass cautions.

Hardware Included with this order

Tighten Key
(Qty - 1)



Mid Rod
(Qty - 1)


Nut
(Qty - 1)



Spring
(Qty - 1)




1




By using your cutting tool, carefully open the package and remove the table and hardware.

2




Set the Table Top down on a flat surface, and **HAND TIGHTEN** the screw into the mounting bracket in the hole closest to the corner of the Table Top.

3




Screw the included rod into the other hole in the mounting bracket and **HAND TIGHTEN** it.

4




Slide the base of the table over the rod as shown in the illustration.

5



Install the table base attachment screw on the rod tip and tighten with the included tighten key.



Congratulations!
You have successfully assembled
your Teardrop Glass Table.