
Assembly Instructions





ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY ●●●●○ DIFFICULT

Tools Required For Assembly:

Allen Wrench  (Included)

Phillips Screwdriver  (Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST,CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY.
PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches . Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjusetment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE.THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc (Right)
Headboard Panel




#2 x 1pc (Left)
Headboard Panel




#3 x 1pc
Left Leg




#4 x 1pc
Right Leg




#5 x 2pcs
Front Legs




#6 x 1pc
Middle Rail (Right)




#7 x 1pc
Middle Rail (Left)



#8 x 2pcs
Lower Rails




#9 x 1pc
Back Middle Rail




#10 x 1pc
Lower Back Middle Rail




#11 x 1pc
Upper Rail




#12 x 1pc
Big Shelf Panel




#13 x 1pc
Key Board Shelf



#14 x 1pc
Right Glider



#15 x 1pc
Left Glider




#16 x 1pc
Front Guard Rail




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#17 x 1pc
Back Guard Rail




#18 x 1pc
Ladder Slat (Right)




#19 x 1pc
Ladder Slat (Left)




#20 x 5pcs
Slats of Ladder




#21 x 1set
Slat Roll (14psc)




#22 x 2pcs (Left)
Vertical Shelf Panel




#23 x 2pcs (Right)
Vertical Shelf Panel




#24 x 4pcs
Side Fix Shelf Panel




#25 x 4pcs
Adjustable Shelf Panel



#26 x 1pc
Middle Fix Shelf Panel



#27 x 2pcs
Back Shelf Panel




#28 x 1pc
Sub Leg Frame




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Hardware List



#A x 34pcs
Bolt 1/4"X3-3/8"



#B x 34pcs
Barrel Nut Ø1/4"x1/2"



#C x 40pcs
Wood Dowel Ø3/8"X1-9/16"



#D x 8pcs
Wood Dowel 5/16"X1-3/16"



#E x 8pcs
Bolt 1/4"X1-9/16"



#F x 30pcs
Bolt 1/4"X1-3/16"



#G x 4pcs
Bolt 5/16"X1-3/16"



#H x 6pcs
Screw Ø5/32"x1-3/16"



#I x 14pcs
Screw Ø1/8"x13/16"



#J x 24pcs
Screw Ø1/8"x19/32"



#K x 2pcs
Base For Ladder



#L x 4pcs
Corrner Bracket



#M x 16pcs
Shelf Pins



#N x 4pcs
Dowel Metal Ø3/8"X4-15/16"



#O x 34pcs
Wood Knob



#P x 10pcs
JCBC Screw Ø9/32"x31/32"




#Q x 2pcs
Allen Wrench



Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.





#A x 8pcs
#B x 8pcs
#C x 4pcs

1. Insert a wood dowel (#C) into the center hole of each end of the middle rail (#6) and lower rail (#8). Then insert the other ends of the dowels into the right leg (#4) and front leg (#5).




2. Insert 2 barrel nuts (#B) in to the holes along the sides of each end of the rails (#6,8). Make sure to face the opening to the hole, then insert 2 bolts into the legs and secure using the Allen wrench (#Q).



#A x 8pcs
#B x 8pcs
#C x 4pcs

2. Insert 2 barrel nuts (#B) into the holes along the sides of each end of the rails (#7,8). Make sure to face the opening to the hole, then insert 2 bolts into the legs and secure using the Allen wrench (#Q).


1. Insert a wood dowel (#C) into the center hole of each end of the middle rail (#7) and lower rail (#8). Then insert the other ends of the dowels into the left leg (#3) and front leg (#5).



#3

#A x 8pcs
#B x 8pcs
#C x 4pcs

1. Insert a wood dowel (#C) into the center hole of each end of the middle back rail (#9) and lower back middle rail (#8). Then insert the other ends of the dowels into the left leg (#3) and right leg (#4).




2. Insert 2 barrel nuts (#B) into the holes along the sides of each end of the rails (#9,10). Make sure to face the opening to the hole, then insert 2 bolts (#A) into the legs and secure using the Allen wrench (#Q).

#4

#F x 6pcs

1. Place the big shelf panel (#12) face down onto a protected surface.


2. Align the left and right gliders (#14,15) to the holes and insert 3 bolts (#F) into each. Secure using the Allen wrench (#Q).





#G x 4pcs


Align the sub leg frame (#28) to the outer sides of the gliders and insert 2 bolts into each glider to connect with the leg. Secure using the Allen wrench (#Q).






#E x 8pcs

Align the big shelf panel (#12) face down to the holes along the middle rails (#6,7) and the back middle rail (#9). Insert a total of 8 bolts (#E) and secure using the Allen wrench (#Q).









Insert the key board shelf (#13).



#A x 10pcs
#B x 10pcs
#C x 8pcs



1. Insert 2 wood dowels (#C) into the top holes of the back guard rail (#17), 1 into the bottom holes, and 1 into each end of the upper rail (#11). Then insert the other ends of the dowels into the headboard panels (#1,2).




2. Insert barrel nuts (#B) into the holes along the sides of each end of the rail (#11,17). Make sure to face the openings to the hole, then insert the bolts (#A) into the headboards and secure using the Allen wrench.



#H x 6pcs


Place the slat roll (#21) onto the bed, then insert a total of 6 screws (#H) an secure using a Phillips screwdriver.





#F x 4pcs


Align the front guard rail (#16) to the upper rail (#11), then insert 2 bolts (#F) into each end and secure using the Allen wrench (#Q).



#11

#N x 4pcs

Insert a dowel metal (#N) into the holes located on the top of the legs. Then with the help of another person, carefully place the top bed onto those dowel metals (#N).




#12

#P x 10pcs
#C x 20pcs
#K x 2pcs
#I x 4pcs

1. Insert 2 wood dowels (#C) into the outer holes located on each end of the slats of ladder (#20). Then insert the other ends of the dowels into the left and right ladder slats (#18,19).

2. Insert a screw (#P) into the the ladder slats (#18, 19) and secure using a Phillips screwdriver.




3. Align the base for ladder (#K) to the ends of the ladder slats, then insert 2 screws (#I) into each and secure using a Phillips screwdriver.

#13

#I x 2pcs


Hook the top of the ladder to the rail and insert 2 screws (#I) from within. Secure using a Phillips screwdriver.



#14

#F x 8pcs
#D x 8pcs

1. Insert a dowel (#D) into the center hole along the shelf panels (22,23,24) and connect as shown below.




2. Insert 2 bolts into each end of the vertical shelf panels (#22,23) and secure using the Allen wrench (#Q).

X2


#15

#J x 12pcs

Place the back shelf panel (#27) onto the the back, then insert a total of 12 screws (#J) and secure.




#16



#17


#F x 4pcs

Align the middle fix shelf panel (#26) in between the vertical shelf panels (#22). Insert 2 bolts (#F) into each end and secure using the Allen wrench.



#18


#M x 16pcs



Insert shelf pins (#M) into desired holes, then apply the adjustable shelf panels (#25).

#19


#I x 8pcs
#L x 4pcs
#O x 34pcs



Align the corner brackets (#L) to the back of the shelf panels and to the legs of the bed, then insert 2 screws (#I) into each and secure using a Phillips screwdriver.

#20

#O x 34pcs



Insert a total of 34 wood knobs (#O).

ASSEMBLY IS COMPLETED

Safety Warnings for Bunk Beds

1. Read and follow the information on the WARNINGS shown on the end structure of the upper bunk and on the carton.
2. Do not remove warning label from the bed.
3. Keep these instructions for future reference.
4. IMPORTANT: **Must use Bunkie mattress or Bunkie board**. The proper sizes for the **UPPER/LOWER TWIN-SIZE** Bunkie mattress or Bunkie board should be 74" - 75" long and 37½" - 38½" wide with no more than 6" thickness and for the **UPPER/LOWER FULL-SIZE** should be 74" - 75" long and 53" - 54" wide with no more than 6" thickness.
5. Surface of mattress must be at least 5 inches (127 mm) **BELOW** the upper edge of guardrails.
6. The **MAXIMUM** weight capacity for the upper bunk is not to exceed 150 lbs.
7. Do not allow children under 6 years of age to use the upper bunk.
8. Periodically check and ensure that the guardrails, ladder, handle and other components are in their proper position, free from damage, and that all connectors are tightened and secured.
9. DO NOT allow horseplay, rough playing or jumping on the beds and do not allow playing or hiding under the beds.
10. Always use the ladder for entering or leaving the upper bunk.
11. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
12. Use of a nightlight may provide added safety precaution for a person using the upper bunk.
13. Always use the guardrails on both sides of the upper bunk.
14. If the bunk bed will be placed next to a wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and the wall.
15. The use of water or sleep flotation mattresses is prohibited.
16. No more than one person is allowed on the upper bunk at all times.



WARNING:
STRANGULATION HAZARD

Never attach or hang objects to any part of the bunk bed that are not designed for use with the bed. Objects such as hanger, hook, belt, bag, rope, string, etc. should not be used on or around the bunk bed.