


INSTALLATION AND CARE INSTRUCTIONS

Top Down-Bottom Up Cordless Honeycomb Shade



PACKAGE CONTENTS

- 2, 3, or 4 mounting brackets, depending on size
- 4–8 screws, depending on size
- 2 rail handles for lifting and lowering shade



TOOLS REQUIRED

Phillips screw driver, pencil

OPERATING AND CLEANING INSTRUCTIONS

Always use the plastic handle to move the shade up and down.
Avoid touching the fabric.


To clean the shade use a vacuum or feather duster.

INSTALLATION

Inside Mount


Flush inside mount requires 2" depth.

- ① Mark location of brackets and screw to the window frame. The brackets should lie 3–4" from each end of where the shade will be installed.



- ② Attach the rail handles to the bottom and top rails.

- ③ Attach the headrail to the brackets as shown. Lower top rail by 3–4", then attach headrail to brackets as shown.



Outside Mount

For maximum draft and light control the headrail should overlap each inside edge of the window by at least 1/2".

- ① Mark location of brackets and screw to the window frame. The brackets should lie 3–4" from each end of where the shade will be installed.

Follow steps 2 and 3 from above.

