


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench




(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.






FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.






Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List

	#1 x 1pc Headboard
	#2 x 2pcs Headboard leg L/R
	#3 x 1pc Stretcher
	#4 x 1pc Footboard
	#5 x 2pcs Side Rails
	#6 x 4pcs Slats
	#7 x 4set Slats Support Legs


Hardware List

	#A x 8pcs Bolt Ø5/16"x1-3/4"
	#Bx 8pcs Lock Washer
	#C x 8pcs Flat Washer
	#D x 1pc Allen Wrench M4
	#E x 4pcs Wood Dowel Ø8*1-1/8"
	#F x 8pcs Screw #4*1-1/4"



#A x 8pcs
#B x 8pcs
#C x 8pcs


1. With the help of another person, carefully place the headboard (#1) onto a protected surface. Align the headboard legs (#2L/R) to the pre-drilled holes. Note, left and right is determined by facing the front of the headboard in its upright position.



2. Prepare 8 bolt assemblies by first inserting the lock washer (#B) onto the bolt (#A) then the flat washer (#C) onto that same bolt (#A). Insert into holes and secure using the Allen wrench (#D).



Hook the ends of the side rails (#5) to the into the slots along the sides of the headboard (#1) and footboard (#4).





#3

Insert the threaded ends of the slat support legs (#7) into the pre-drilled holes along the sides of the slats (#6). Turn right to tighten.

#6

X4


#7




#4

#F x 8pcs

Align the ends of the slats (#6) to the pre-drilled holes along the sides of the side rails (#5). Insert a screw (#F) into each hole and secure using a Phillips screwdriver.



Make sure all bolts are firmly secured.



ASSEMBLY IS COMPLETED