


INSTALLATION GUIDE

Living Room Chair










Cautions

Please read this manual carefully before assembly and use, and keep it properly for future reference.

- ⚠ 1. Please check the manual carefully to confirm that you have received all parts.
- ⚠ 2. If any parts are missing, please inform us of their letter labels. If possible, send photos of all the accessories you have received – this will help us assist you more effectively.
- ⚠ 3. If any parts are damaged, please send clear photos to us. We will review the photos and provide you with the optimal solution as soon as possible.


Components List

Ⓐ Backrest Frame  x1	Ⓑ Cushion  x1
Ⓒ Throw Pillow  x1	Ⓓ Chair Leg  x2
Ⓔ M8 Screw  M8x35mm x6	Ⓕ M6 Screw  M6x65mm x4
Ⓖ Allen Wrench  x1	Ⓗ Screw Cover Cap  x6

Assembly Instruction


STEP 1

Fasten the left chair leg to one side of the seat cushion, then secure the right chair leg to the other side.




STEP 3

Fit the screw cover caps into place.



STEP 2

Connect the backrest to the chair legs with screws and tighten the screws securely.



STEP 4

Place the Throw Pillow in position to complete the assembly.

