
ASSEMBLY INSTRUCTION ARM CHAIR

		PARTS	S L	IST			
PARTS#	PARTS NAME	DRAWING	QTY	PARTS#	PARTS NAME	DRAWING	QTY
A	FLAT WASHER 5/16"X 3/4"	0	9	L	PLUG	DATATIO	
В	LOCK WASHER 5/16"	0	9	-		O	2
С	BOLTS DIA 5/16"X3"		4	М	FRONT LEG		2
D	BOLTS DIA 5/16"X2-1/2"		4	N	LEFT ARM	2	1
E	BOLTS DIA 5/16"X1 1/2"		1	0	RIGHT ARM		
F	ALLEN WRENCH 5/16"		1		KIUHI AKW	B	1
G	FLAT WASHER 1/4"X 5/8"	0	6	P	SEAT FRAME		1
Н	LOCK WASHER 1/4"	0	6				
I	BOLTS DIA 1/4"X1 1/2"		2	Q	CHAIR BACK		1
J	BOLTS DIA 1/4"XI 1/4"		4				
K	ALLEN WRENCH 1/4"		1				

Note: Do Not tighten bolts until assembly is fully completed.

STEP 1.

Remove all parts from carton and separate them into part number groups as indicated on the part list. Place the chair back (Q) on a smooth flat surface with the holes facing up. Loosely tighten all bolts until instructed to fully tighten at the end of step.




ASSEMBLY INSTRUCTION ROUND TABLE

		PART	S L	IST			
PARTS#	PARTS NAME	DRAWING	QTY	PARTS#	PARTS NAME	DRAWING	QTY
A	FLAT WASHER 5/16"X 3/4"	0	8	E	LEG		4
В	LOCK WASHER 5/16"	0	8		DDO		
С	BOLTS DIA 5/16"X1-1/2"		8	F	TOP FRAME		1
D	ALLEN WRENCH 5/16"		1				

Note: Do Not tighten bolts until assembly is fully completed.


STEP 1.

Remove all parts from carton and separate them into part number groups as indicated on the part list. Place the table top (F) on a smooth flat surface with the holes facing up. Loosely tighten all bolts until instructed to fully tighten at the end of step.



STEP 2.

Attached leg (E) to top frame (F). Insert flat washer (A) lock washer (B) and bolts (C). Use allen wrench (D) to secure bolts (C). Set the assembled table upright on a level surface & fully tighten all bolts securely.




Warnings : Failure to observe these warnings can result in serious injury and/or product damage:

- * Never stand on the table.
- * Periodically re-tighten all bolts.

ASSEMBLY INSTRUCTION ARM CHAIR

STEP 2.

Attach seat frame (P) to chair back (Q). Insert flat washer (A) lock washer (B) and bolts (E) through center hole of back rail. Insert flat washer (A) lock washer (B) and bolts (C) through corner block to back leg. Use allen wrench (F) to secure bolts (C, E). Tighten



CaWarnings : Failure to observe these warnings can result in serious injury and/or product damage:

* Never stand on the chair.

slightly not fully.

- * Never use the chair as a ladder.
- * Do not tip the chair when seated.
- * Periodically re-tighten all bolts.
- * Do not exceed 250lbs. (113.4kgs) weight limit on the chair.