
Assembly Instruction

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing. Please keep all hardware parts out of the reach of children.

- 1) We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to person during assembly.
- 2) Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3) Please do not over tighten screws or bolts.
- 4) Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST

FIGURE	DESCRIPTION	Q'TY
	Hardware Bag	1 Pc
	Chair Back	1 Pc
	Cushion Seat	1 Pc
	Front Leg	2 Pcs



PAGE 1 OF 2


Assembly Instruction

HARDWARE PARTS:

()	Опининания	© management of the second			
JCBC Bolt	JCBC Bolt	JCBC Bolt			_
80mm	63mm	40mm	Lock Washer	Flat Washer	Allen Key
4 pcs	4 pcs	3 pcs	11 pcs	11 pcs	1 pc


Step 1: Attached the cushion seat to the chair back using the provided hardware as shown on Fig. 1.1 and Fig. 1.2.

Step 2: Attached Front Legs to Cushion Seat using the provided hardware as shown in Fig. 2.1.



STEP 3

Turn the chair to standing position. Check it's balance and tighten all screw and bolt to complete the assembly.



CARE INSTRUCTION

- Be sure to use the same type of publish consistenty.
 Your furniture will appear cloudy or streaky if oill based or wax based polishes are intercharged.
- Spray your furniture surface evenIt. Wipe in a circular motion with a solt clean cloth.