


ASSEMBLY INSTRUCTION













REAR











FRONT




PART LIST

1 Top Panel  1pc	2 Bottom Panel  1pc	3-L Side Panel (Left)  1pc	3-R Side Panel (Right)  1pc	4 Division Panel  1pc	5-A Door  2pcs
5-B Door  2pcs	6 Leg  2pcs	7 Shelf Panel  2pcs	8 Back Panel  1pc	9 Support Rail  2pcs	10 Bottom Rail  1pc


HARDWARE LIST

A MINI FIX SPREADING BOLT 24MM  18pcs	B MINIFIX HOUSING Ø15*12MM  18pcs	C WOOD DOWEL M8*30MM  20pcs	D JCBC M6*30MM  6pcs	E SCREW M4*30MM  8pcs	F SCREW M3.5*16MM  48pcs
G PAN HEAD M3.5*16MM  20pcs	H SHELF SUPPORT  8pcs	I ALLEN KEY M4  1pc	J HINGES  4pcs	K HINGES  4pcs	L HANDLE  4sets


STEP 1



STEP 2





C X 4pcs


E X 8pcs



A X 9pcs


B X 9pcs



C X 6pcs



STEP 3




STEP 4




A X 9pcs




B X 9pcs



C X 6pcs



C X 2pcs




D X 3pcs



I X 1pc

STEP 5




 C X 2pcs


 D X 3pcs

 I X 1pc



STEP 6




 G X 20pcs



STEP 7



STEP 8




F X 16pcs



J X 4pcs




K X 4pcs





H X 8pcs


STEP 9




STEP 10





F X 32pcs




L X 4sets




COMPLETED ASSEMBLY



ASSEMBLY INSTRUCTIONS


How to Concealed Hinges

Height Adjustment-helps you to adjust doors so they align at the top and bottom.




Note: Run your hand along the underside of the doors. You will easily feel which door are sitting lower than the others.

Depth Adjustment- Lets you bring a door into alignment with vertical surfaces such as drawers.



Note: Check to make sure you are not missing a door bumper. Missing door bumpers will cause your cabinet to look out of alignment.

Side Adjustment- adjusts gaps between doors and alleviates rubbing doors.



Note: Right Side Hinge: Clockwise moves door to RIGHT, CCW moves door to LEFT.
Left Side Hinge: Clockwise moves door to LEFT, CCW door to RIGHT.